



Wake'n' Shake Curve



WNS10 USER GUIDE

KEEP THIS USER GUIDE FOR FUTURE REFERENCE
Always retain your proof of purchase in case of warranty service.
AUSTRALIA: www.oricom.com.au

BATTERY INSTALLATION

Your clock requires 1 x AAA and 2 x AA alkaline batteries (included) to operate.

1. Place your unit face down on a flat surface.
2. Press the latch and remove the battery cover at the back of your unit.
3. Insert 1 x AAA and 2 x AA new alkaline batteries into the battery compartment by observing the correct "+" and "-" polarity.
4. Replace the battery cover.

AUTO KEY-LOCK

Auto key-lock applies to all other buttons (if no buttons are pressed after 1 minute). Press and hold / DOWN button to release the key lock, two soft and short beep tones will be heard.

TO SET TIME AND THE SNOOZE DURATION

1. Press and hold **SET / TIMER**, the hour digits "0" flash. Press or to set the time in hours (hold or to advance rapidly).
2. Press **SET / TIMER** again, the minute digits "00" flash. Press or to set the time in minutes (hold or to advance rapidly).
3. Press **SET / TIMER** again, the display shows "24Hr" and flashes. Press or to select "12Hr" or "24Hr" time format. The **AM** icon appears to indicate the morning time and **PM** icon to indicate the afternoon time.
4. Press **SET / TIMER** again, the display shows "05" and flashes. Press or to select your snooze time from 5 to 60 minutes.
5. Press **SET / TIMER** to exit the setting mode, (or if no key has been pressed for approx. 10 seconds).

THE ALARM (default at 6:00 AM)

1. Press and hold **AL SET / SELECT**, the **AL** appears and the alarm's hour digits' flash. Press or to set the alarm in hours (hold or to advance rapidly).
2. Press **AL SET / SELECT** once again, the alarm's minute digits' flash. Press or to set the alarm in minutes (hold or to advance rapidly).
3. Press **AL SET / SELECT** again, and "**HI**" flash (vibration at HI level), press or to select "**LO**" (vibration at Low level) if needed.
4. Press **AL SET / SELECT** again, and "**HI**" flash (Sound at HIGH level), press or to select "**LO**" (Sound at Low level) if need.
5. Press **AL SET/SELECT** once again or no button around 10 seconds to exit the alarm setting mode. Admist alarm setting, press **SET / TIMER** once to exit and return to normal time display mode.

TO SELECT THE ALARM MODE

At normal time display mode, press **AL SET / SELECT** one at a time to activate the alarm(s), the corresponding alarm indicator(s) on the right side of the time display will be on:

only sound alarm is activated	only shaker alarm is activated	only strobe light alarm is activated	both sound and vibration alarm are activated	both strobe light and sound alarm are activated

Press **AL SET / SELECT** once more to turn off all the alarms, all alarm indicators disappear.

TO STOP AND RESET THE ALARM TO COME ON THE NEXT DAY

When alarm is sounding, the corresponding alarm indicator flashes. Press **AL SET / SELECT** once to stop the alarm and reset it to come on the following day. After that, the corresponding alarm indicator stays on the display.

TO USE SNOOZE

When the alarm is sounding, press **Zz** • once, the alarm will be stopped temporarily and the corresponding alarm indicator will keep flashing. Alarm will come on again after the set snooze duration is over.

TO USE BACKLIGHT

Press **Zz** • once to activate the backlight 5 seconds.

TO USE FLASHLIGHT

Press and hold **Zz** • to activate the flashlight. Press and hold **Zz** • to de-activate the flashlight.

TO USE COUNTDOWN TIMER (HOUR-MINUTE TIMER)

1. At normal time display, press **SET / TIMER** once, display change to timer mode, and will appear with "0:00" flash.
2. Press to adjust countdown timer in hours, press to adjust countdown time in minutes.
3. Press **START / STOP** once to start countdown in minutes, then "." and " flash.
4. During counting down, press **START / STOP** to pause counting down and the whole display flashes. Press and hold **START / STOP** to stop or reset the counting down timer.
5. Press **START / STOP** again for continuous counting down. "." and " flash again.
6. When the timer reaches "0:00" (00 seconds), the clock vibrates / sounds / flashes with LED and it starts to count up to show the overrun time. Press **START / STOP** once to stop the timer alarm.
7. Press **START / STOP** again, the display shows last count down set time and flashes. Repeat Step 2-5 to set and use countdown timer.

Remark: When timer is active and counting down or up, press the **SET / TIMER** can return to the time display. The timer icon will flash on the normal time display.

Press SET / TIMER once to enter timer mode.	Press or to set countdown time	Press START / STOP once to count down	Press START / STOP to pause count down	When countdown timer reaches 0:00 (0 seconds), the clock vibrates/ sounds/ flashes and starts to count up to show the elapsed time. Press START / STOP once to stop the timer alarm.

TO USE COUNT-UP TIMER (MAX. 23HR 59MIN.)

1. At normal time display, press **SET / TIMER** once, display changes to timer mode and flashes. Press and hold **START / STOP** to reset timer value to "0:00".
2. Press **START / STOP** once to start count up timer. "." and " flash.
3. During counting, press **START / STOP** once to pause counting up and whole display flashes. Press and hold **START / STOP** to stop or reset the counting up timer.
4. Press **START / STOP** once again to continue counting up.

	When timer value is reset to 0:00 (Press and hold START / STOP), press START / STOP once to start count-up.
--	--

Remark: When timer is active and counting down or up, press the **SET / TIMER** button. It will return to the time display. The timer icon will flash on the normal time display.

TEST MODE

Press and hold / **TEST** button, strobe light flashing, shaker vibrating and buzzer sounding for 5 seconds and then stops.

LOW BATTERY ALERT

When the battery level becomes low, an low battery icon will appear on the upper middle of the LCD. Replace batteries with new alkaline batteries.

Remark: Frequent use of the vibration alarm will quickly shorten the battery life.

TROUBLE SHOOTING

If your clock displays irrelevant time or does not function properly, which may be caused by electro-static discharge or other interference, open the battery cover, take out the batteries and reinstall them by observing the correct +/- polarity. Your clock will be reset to default settings and you need to set it again. Low battery level will decrease the vibration and the alarm sound. Once this happens, replace batteries with new ones.

CARE OF YOUR PRODUCT

1. Place your clock on a stable surface, away from sources of direct sunlight or excessive heat or moisture.
2. Protect your furniture when placing your units on a natural wood and lacquered finish by using a cloth or protective material between it and the furniture.
3. Clean your unit with a soft cloth moistened only with mild soap and water. Stronger agents such as Benzene, thinner or similar materials can damage the surface of the unit. Make sure the unit is unplugged before cleaning.
4. If the unit is not to be used for a prolonged period, such as a month or longer, remove the batteries to prevent possible corrosion. Should the battery compartment become corroded or dirty, clean the compartment thoroughly and replace the batteries.

SPECIFICATIONS

Alarm duration	: 1 minute	
Snooze duration Adjustable	: 5 to 60 minutes	
Default settings	Time format	24 hour
	Time	0:00
	Alarm	6:00
	Shaker alarm level	Hi
	Snooze duration	05 (5 minutes)
Count-up / countdown time	23 hours 59 minutes	
Audible alarm	: up to 75 dB at 1m	

Express Warranty (Australia)

This Express Warranty is provided by Oricom International Pty Ltd ABN 46 086 116 369, Unit 1, 4 Sovereign Place, South Windsor NSW 2756, herein after referred to as "Oricom". Oricom products come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

Oricom warrants that the product is free from defects in materials or workmanship during the Express Warranty Period. This Express Warranty does not extend to any product from which the serial number has been removed or was purchased outside of Australia.

Nothing in this Express Warranty excludes, restricts or modifies any condition, warranty, guarantee, implied term, right or remedy pursuant to the Australian Consumer Law and which may not be so excluded, restricted or modified. For such conditions, terms, guarantees and warranties that cannot be excluded, restricted or modified, Oricom limits the remedies available to extent permitted in the relevant legislation.

The Express Warranty Period will be 2 years from the date of purchase of the product evidenced by your dated sales receipt. You are required to provide proof of purchase as a condition of receiving Express Warranty services.

You are entitled to a replacement product or repair of the product at our discretion according to the terms and conditions of this document if your product is found to be faulty within the Express Warranty Period. This Express Warranty extends to the original purchaser only and is not transferable.

Products distributed by Oricom are manufactured using new materials or new and used materials equivalent to new in performance and reliability. Spare parts may be new or equivalent to new. Spare parts are warranted to be free from defects in material or workmanship for thirty (30) days or for the remainder of the Express Warranty Period of the Oricom branded product in which they are installed, whichever is longer. During the Express Warranty Period, Oricom will where possible repair and if not replace the faulty product or part thereof. All component parts removed under this Express Warranty become the property of Oricom. In the unlikely event that your Oricom product has a recurring failure, Oricom may always, subject to the Competition and Consumer Act 2010, at its discretion, elect to provide you with a replacement product of its choosing that is at least equivalent to your product in performance.

No change to the conditions of this Express Warranty is valid unless it is made in writing and signed by an authorised representative of Oricom.

Oricom will not be liable under this Express Warranty, and to the extent permitted by law will not be liable for any defect, loss, damage or injury arising out of or in connection with a:

1. Failure by you to adhere to the warnings and follow the instructions set out in this user guide for the proper installation and use of the product;
2. Wilful misconduct or deliberate misuse by you of the product;
3. Any external cause beyond our control, including but not limited to power failure, lightning or over voltage; or
4. Modification to the product or services carried out on the product by anyone other than Oricom or Oricom's authorised service provider.

How to make a claim under your Express Warranty in Australia

Oricom has a simple warranty process for you to follow:

- Please call or email our Customer Support Team, 1300 889 785 or support@oricom.com.au.
- A Customer Support Team member will verify after troubleshooting with you if your product qualifies under warranty. If so, they will give you a Product Return Authorisation number.
- We will then email or fax a Return Authorisation form and a Repair Notice (if necessary), together with instructions on how to return the goods for warranty service.

Please note that if a Customer Support Team member advises that your product does not qualify for return, this warranty does not apply to your product. Products that are authorised to be returned to Oricom in Australia must include all of the following:

- A completed Return Authorisation form
- A copy of your Proof of Purchase (please keep your original copy)
- The faulty product, including all accessories.

Send the approved returns to:

Oricom International Pty Ltd
Locked Bag 658
South Windsor NSW 2756 Australia

Please note that this Express Warranty excludes expenses incurred by you in returning any faulty product to us. You must arrange and pay any expenses incurred (including postage, delivery, freight, transportation or insurance of the product) to return the faulty product to us, however, we will arrange delivery of the repaired or replaced faulty product to you.

Important Information

Repair Notice

Please be aware that the repair of your goods may result in the loss of any usergenerated data (such as stored telephone numbers, text messages and contact information). Please ensure that you have made a copy of any data saved on your goods before sending for repair. Please also be aware that goods presented for repair may be replaced by refurbished goods or parts of the same type rather than being repaired.

ORICOM CUSTOMER SUPPORT

Oricom have a trained and dedicated team of Customer Support Representatives, each with the knowledge and resources to assist in answering your questions quickly and efficiently.

Oricom Support - Australia

For all product enquiries, troubleshooting or to discuss the range of Oricom products, feel free to contact Oricom or visit our website for answers to frequently asked questions.

1300 889 785

Monday - Friday 8am – 6pm AEST
Email: support@oricom.com.au
www.oricom.com.au

Oricom Support - New Zealand

0800 674 266

Monday - Friday 10am - 8pm NZST
Email: support@oricom.co.nz
www.oricom.co.nz

