

## **FITTING INSTRUCTIONS**



## **Pack includes**

3dBi Mono pole antenna with heavy duty spring and base Length of antenna is 660mm with 22mm fiberglass radome

**IMPORTANT** - Always fit in accordance with State Road & Traffic Safety Guidelines

## Installation

- 1. Remove the shroud protecting the cable at the base of the antenna.
- 2. Install the spring base onto the bracket (not supplied). tigthen in a clockwise direction using a hexagon wrench or spanner. IMPORTANT: Do not exceed 50N.

