

08BUN User Guide

KEEP THIS USER GUIDE FOR FUTURE REFERENCE
Always retain your proof of purchase in case of warranty service.
Risk of suffocation!
Keep all packaging materials out of reach of children.



	Power Switch Use a paper clip or similar shaped tool to press the power switch to turn the LCD display ON.
	On/Off This will turn off the screen and backlight. Device will wake when the alarm time is reached.
	Adjust Backlight (7 levels of brightness) Press to increase brightness. Press to decrease brightness.
	Press once to set 'wake-up time' Backlight will change from red to orange (<i>Range allowed 04:00AM – 2:59PM.</i>) To Set: Hold for 3 seconds → Adjust hour: → Press → Adjust minute: To add/remove alarm sound: Press at any stage while setting. A bell icon will appear when turned on. Any button will turn off alarm when it sounds. <i>Note: Hold both + and – for 3 seconds to return to default setting (6:00AM)</i>
	Press twice to set 'sleep time' Backlight will change from orange to red (<i>Range allowed 3:00PM – 3:59AM.</i>) To Set: Hold for 3 seconds → Adjust hour: → Press → Adjust minute: <i>Note: Hold both + and – for 3 seconds to return to default setting (6:00PM)</i>
	Press three times to set 'Current Time' To Set Time: Hold for 3 seconds → Adjust hour: → Press → Adjust minute:
	Reset To reset all settings to default setting (except current clock setting) Press and hold all three buttons at once: + + until CLr appears on the display.
	Lock Lock clock to prevent settings from being accidentally changed. To Lock or Unlock: Press and hold for 5 seconds.
	Low Battery Alert When battery becomes low, the BAT icon will appear. When clock battery is low, backlight will be turned off. Tip: When not in use for an extended period, charging every two months will help protect the life of the lithium battery.

Specifications: USB power adaptor: 5V-500mA (not supplied)/Battery: 3.7V 500mAh Lithium/Charge time: 2~3 Hours
Warnings: • For your continued safety and the reliability of your clock, please observe normal electrical safety precautions.
• This product is not a toy, keep out of reach of children. Rechargeable Lithium Ion batteries are potentially hazardous and can present a serious fire hazard if damaged, defective or improperly used. Do not leave your product unattended whilst charging the battery.
• Keep the product away from water and moisture. It's intended for indoor use only.
• This product does not include any user serviceable parts. DO NOT DISASSEMBLE THIS PRODUCT.
• Dispose of this product which includes a lithium battery in accordance with local disposal waste regulations.

Express Warranty (Australia)

This Express Warranty is provided by Oricom International Pty Ltd ABN 46 086 116 369, Unit 1, 4 Sovereign Place, South Windsor NSW 2756, herein after referred to as “Oricom”.

Oricom warrants that the product is free from defects in materials or workmanship during the Express Warranty Period. This Express Warranty does not extend to any product from which the serial number has been removed or was purchased outside of Australia.

The benefits of this Express Warranty are in addition to other rights and remedies you may have under the Australian Consumer Law. Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure. In the event of a minor failure, Oricom reserves the right to choose to repair or replace the product.

The Express Warranty Period will be a period of 12 months beginning on the date of purchase of the product evidenced by your dated sales receipt. You are required to provide proof of purchase as a condition of receiving Express Warranty services.

You are entitled to a replacement product or repair of the product at our discretion according to the terms and conditions of this document if your product is found to be faulty within the Express Warranty Period. This Express Warranty extends to the original purchaser only and is not transferable.

Products distributed by Oricom are manufactured using new materials or new and used materials equivalent to new in performance and reliability. Spare parts may be new or equivalent to new. Spare parts are warranted to be free from defects in material or workmanship for thirty (30) days or for the remainder of the Express Warranty Period of the Oricom branded product in which they are installed, whichever is longer. During the Express Warranty Period, Oricom will where possible repair and if not replace the faulty product or part thereof. All component parts removed under this Express Warranty become the property of Oricom. In the unlikely event that your Oricom product has a recurring failure, Oricom may always, subject to the Competition and Consumer Act 2010, at its discretion, elect to provide you with a replacement product of its choosing that is at least equivalent to your product in performance.

No change to the conditions of this Express Warranty is valid unless it is made in writing and signed by an authorised representative of Oricom. Oricom will not be liable under this Express Warranty, and to the extent permitted by law will not be liable for any defect, loss, damage or injury arising out of or in connection with a:

1. Failure by you to adhere to the warnings and follow the instructions set out in this user guide for the proper installation and use of the product;
2. Willful misconduct or deliberate misuse by you of the product;
3. Any external cause beyond our control, including but not limited to power failure, lightning or over voltage; or
4. Modification to the product or services carried out on the product by anyone other than Oricom or Oricom’s authorised service provider.

How to make a claim under your Express Warranty in Australia

Oricom has a simple warranty process for you to follow:

- Please call or email our Customer Support Team, 02 4574 8888 or support@oricom.com.au.
- A Customer Support Team member will verify after troubleshooting with you if your product qualifies under warranty. If so, they will give you a Product Return Authorisation number.
- We will then email a Return Authorisation form and a Repair Notice (if necessary), together with instructions on how to return the product for warranty service.

Please note that if a Customer Support Team member advises that your product does not qualify for return, this warranty does not apply to your product. Products that are authorised to be returned to Oricom in Australia must include all of the following:

- A completed Return Authorisation form
- A copy of your Proof of Purchase (please keep your original copy)
- The faulty product, including all accessories.

Send the approved returns to:

Oricom International Pty Ltd
Locked Bag 658
South Windsor NSW 2756 Australia

Please note that this Express Warranty excludes expenses incurred by you in returning any faulty product to us. You must arrange and pay any expenses incurred (including postage, delivery, freight, transportation or insurance of the product) to return the faulty product to us, however, we will arrange delivery of the repaired or replaced faulty product to you.

Important Information - Repair Notice

Please be aware that the repair of your products may result in the loss of any user-generated data (such as stored telephone numbers, text messages and contact information). Please ensure that you have made a copy of any data saved on your product before sending for repair. Please also be aware that products presented for repair may be replaced by refurbished products or parts of the same type rather than being repaired.

ORICOM CUSTOMER SUPPORT

Oricom have a trained and dedicated team of Customer Support Representatives, each with the knowledge and resources to assist in answering your questions quickly and efficiently.

Oricom Support - Australia

For all product enquiries, troubleshooting or to discuss the range of Oricom products, feel free to contact Oricom or visit our website for answers to frequently asked questions.

02 4574 8888
Monday - Friday 8am – 6pm AEST
Email: support@oricom.com.au
www.oricom.com.au

Oricom Support - New Zealand

0800 674 266
Monday - Friday 10am - 8pm NZST
Email: support@oricom.co.nz

