

oricom®

Video Baby Monitor Secure748WSP



User Guide

KEEP THIS USER GUIDE FOR FUTURE REFERENCE

Always retain your proof of purchase in case of warranty service.
AUSTRALIA: www.oricom.com.au

PACKAGE LIST

This User's Guide provides you with all the information you need to get the most from your product.

Before you can use the baby monitor, we recommend you fully charge the battery in the parent unit. Please read the Safety Instructions on page 1 before setting up and using your monitor.

Package List:

Name	Qty
Parent unit	1
Baby unit	1
Power adaptor	2
User manual	1
Shaker	1

TABLE OF CONTENTS

SAFETY INFORMATION	1
OVERVIEW OF YOUR BABY MONITOR	5
SETTING UP YOUR VIDEO BABY MONITOR	7
MONITOR SCREEN ICONS	8
MENU FUNCTION	9
EXPRESS WARRANTY	16

Need Help?

If you need assistance setting up or using your Oricom product now or in the future, call Oricom Support.

Australia

02 4574 8888

www.oricom.com.au

Mon-Fri 8am – 6pm AEST

New Zealand

0800 67 42 66

www.oricom.co.nz

Mon-Fri 10am – 8pm NZST

1 SAFETY INFORMATION

1 Important Safety Information

- It is very important that you read the User Guide carefully as it contains detailed information you will need to get the most from your Oricom baby monitor. If you have any issues setting up or using your Oricom baby monitor, please call our Customer Support team.
- Your Oricom baby monitor is designed to be an aid and should not be used as a substitute for responsible and proper adult supervision of a child.
- The baby monitor has been designed to provide some added reassurance in the form of sound and video transmission for those times when you are not in the same room as your baby, provided you always stay within hearing range of the baby monitor during use. Your baby monitor is not a medical device, nor a device to prevent cases of Sudden Infant Death Syndrome (SIDS) or "cot death", and you should not rely on it for your baby's wellbeing. It is important that you regularly check on your baby personally.
- Make sure the baby unit, parent unit and mains adaptor cables are kept out of reach of your baby and other young children at all times, at least one metre away. The baby monitor is not a Toy.
- Never place the baby unit or parent unit inside your baby's cot, bed or playpen.

SAFETY INFORMATION 2

- Never cover the parent or baby units with clothes, towels, blankets or any other item. Never use or place your parent or baby unit in or near moisture or water (e.g. near bath or pool). Immersing in water could cause electric shock and even death.
- The installation location plays an important role in ensuring proper operation. Therefore, maintain a distance of at least one metre from other electronic equipment, such as microwave ovens or Wi-Fi devices, otherwise they could cause interference. During continual use, the baby unit power adaptor may become warm to the touch. This is normal and should not be a concern.



Warning

Risk of suffocation!

Keep all packaging materials out of reach of children.

3

SAFETY INFORMATION

Battery safety

- Batteries represent a hazard to health and the environment!
- They contain toxic, ecologically hazardous heavy metals. Do not dispose of batteries in a fire as they may explode. Dispose of batteries according to local regulations, never in your household rubbish.
- Do not dismantle, cut, open, crush, bend, puncture, or shred cells or batteries. If a battery leaks, do not let the battery liquid touch skin or eyes. If this happens, immediately flush the affected areas with water, and seek medical assistance.
- Do not modify, remanufacture, attempt to insert foreign objects into the battery, or immerse or expose it to water or other liquids. Batteries may explode if damaged.
- Use only the battery supplied with the baby monitor. Improper use, or use of unapproved batteries, may present a risk of fire, explosion, or other hazard, and may invalidate any approval or warranty.
- If you believe the battery is damaged, remove parent unit from the charger and stop using it. Contact Oricom for assistance. Never use a damaged battery.
- If monitor will not be used for a long time, charge battery to 40%~50% capacity, store battery in a dry environment at about 25°C.
Charge and discharge battery every 3 months.

Disposal


Always dispose of your products at the end of their life in accordance with your local waste disposal requirements.

Packaging materials including cardboard and paper packaging, should be recycled in accordance with your local council waste regulations.

OVERVIEW OF YOUR BABY MONITOR

5

Parent Unit




- ① POWER BUTTON
- ② MENU/BACK BUTTON
- ③ VOL +/-
- ④ NAVIGATION KEYS
- ⑤ OK BUTTON
- ⑥ TALK/ZOOM BUTTON
- ⑦ MIC
- ⑧ LED LIGHT
- ⑨ SHAKER CONNECTION
- ⑩ POWER CONNECTION

Parent Unit - Basic operation of the keys	
Power button	Turn ON/OFF - Press and Hold 3 seconds. Screen Sleep/Wake - Press One time
Menu button	Press to access menu
Back button	Press to go back
Talk button	Press and hold to talk
Zoom button	Press to digital zoom
+/- button	Press to adjust volume level

OVERVIEW OF YOUR BABY MONITOR

6

Camera Unit



- ① POWER PORT
- ② ON/OFF SWITCH
- ③ PAIR BUTTON
- ④ TEMPERATURE SENSOR


Flashing LED and Vibrating Shaker

This baby monitor has flashing light and vibrating shaker alert features to assist parents with hearing impairments. To turn the flashing light alert feature "ON" go to page 15 in this user guide. Once turned on the LED light will flash when motion or VOX alerts are activated (see page 13 to turn "ON" motion detection and page 14 to turn "ON" VOX). In addition to the LED flashing light, you can plug in the vibrating shaker (see page 5 for plug in location) to also get vibrating alerts.

SETTING UP YOUR VIDEO BABY MONITOR

1. Setting up your Video Baby Monitor

1.1. Connecting the power adaptor to the baby unit



- Connect the small plug of the power adaptor to the rear of the Baby Unit. The other end will plug into mains power socket.
- Only use the supplied adaptor (5V DC/1.5A).



Warning

Do not place the AC Adaptor cable in a high "wear and tear" location. Never use a frayed or compromised cord.

Strangulation Hazard: Children have been **STRANGLED** with cords. Keep this cord out of the reach of children (more than 1 metre away).

2. Monitoring Screen Icons



- ① Signal strength indicator
- ② Camera number
- ③ Vocal/Mute mode
- ④ Lullabies
- ⑤ Motion Detecting
- ⑥ Feeding Timer
- ⑦ VOX mode
- ⑧ Temperature Alarm
- ⑨ Room temperature
- ⑩ Time
- ⑪ Battery indicator

9 MENU FUNCTION

3. Menu function (Parent Unit)

3.1 Camera

You can add up to 4 cameras to your parent unit.
Select “Camera”--Select “Add Camera”--Press “OK”--
Press the Pairing Button on Baby Unit




1



2



3



4

3.2 View

Select camera to view (when multiple cameras are paired to parent unit)

3.3 Lullabies

Choose a lullaby to play, you can also choose to play All lullabies and adjust the lullaby playing volume.

3.4 Feeding Timer

Choose a feeding time from one of the preset times, 2, 3, 4 or 5 hours or enter a duration period manually by selecting "setting" and entering a time. Alarm duration is 5 seconds.

3.5 Setting

3.5.1 Language Setting


Select one of 5 languages
(English, Deutsch, Dutch, Francais, Espanol).



11 MENU FUNCTION

3.5.2 Brightness Setting

Adjust brightness level.



3.5.3 Date & Time

Set date and time. (Day / Month / Year)



MENU FUNCTION 12

3.5.4 Temperature Setting

You can set the high and low temperature alerts, or turn them off.



3.5.5 Temp. °C/°F

Choose temperature format Celsius/Fahrenheit (°C/°F).



13 MENU FUNCTION

3.5.6 Frequency

Select preferred wireless frequency - 60Hz/50Hz. 60Hz is smoother than 50Hz, but will consume more battery power.



3.5.7 Motion Detection

Turning this feature on will give you an alert when motion is detected.



MENU FUNCTION 14

3.5.8 Sound Sensitivity Level VOX

Select the level of sound detection sensitivity, the parent unit will sound an alert when sound is detected.



3.5.9 LCD Always On

Select ON/OFF.

When LCD always on is set to "OFF" the screen will automatically turn off after 10 seconds to save battery power, you can wake the screen by pressing any button.



15 MENU FUNCTION

3.5.10 Default Setting

Select YES / NO to restore factory default setting.




3.5.11 Alarm Mode Settings

Set Alarm Sound level (Off, 1 to 5 levels) using Right or Left arrow.

Press down arrow to select Flash Light.

Select ON/OFF with the Right or Left arrow keys.

Press OK button to save your selection.



NOTE: A vibrating shaker is included, when plugged in this will vibrate when an alert sounds. To use the shaker, plug into the shaker connection on the side of the parent unit (Number 9 on page 5).

EXPRESS WARRANTY 16

Express Warranty (Australia)

This Express Warranty is provided by Oricom International Pty Ltd ABN 46 086 116 369, Unit 1, 4 Sovereign Place, South Windsor NSW 2756, herein after referred to as “Oricom”.

Oricom warrants that the product is free from defects in materials or workmanship during the Express Warranty Period. This Express Warranty does not extend to any product from which the serial number has been removed or was purchased outside of Australia.

The benefits of this Express Warranty are in addition to other rights and remedies you may have under the Australian Consumer Law. Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure. In the event of a minor failure, Oricom reserves the right to choose to repair or replace the product.

The Express Warranty Period will be a period of 3 years beginning on the date of purchase of the product evidenced by your dated sales receipt. You are required to provide proof of purchase as a condition of receiving Express Warranty services.

17 EXPRESS WARRANTY

You are entitled to a replacement product or repair of the product at our discretion according to the terms and conditions of this document if your product is found to be faulty within the Express Warranty Period. This Express Warranty extends to the original purchaser only and is not transferable.

Products distributed by Oricom are manufactured using new materials or new and used materials equivalent to new in performance and reliability. Spare parts may be new or equivalent to new. Spare parts are warranted to be free from defects in material or workmanship for thirty (30) days or for the remainder of the Express Warranty Period of the Oricom branded product in which they are installed, whichever is longer. During the Express Warranty Period, Oricom will where possible repair and if not replace the faulty product or part thereof. All component parts removed under this Express Warranty become the property of Oricom. In the unlikely event that your Oricom product has a recurring failure, Oricom may always, subject to the Competition and Consumer Act 2010, at its discretion, elect to provide you with a replacement product of its choosing that is at least equivalent to your product in performance.

No change to the conditions of this Express Warranty is valid unless it is made in writing and signed by an authorised representative of Oricom.

EXPRESS WARRANTY 18

Oricom will not be liable under this Express Warranty, and to the extent permitted by law will not be liable for any defect, loss, damage or injury arising out of or in connection with a:

1. Failure by you to adhere to the warnings and follow the instructions set out in this user guide for the proper installation and use of the product;
2. Willful misconduct or deliberate misuse by you of the product;
3. Any external cause beyond our control, including but not limited to power failure, lightning or over voltage; or
4. Modification to the product or services carried out on the product by anyone other than Oricom or Oricom's authorised service provider.

19 EXPRESS WARRANTY

How to make a claim under your Express Warranty in Australia

Oricom has a simple warranty process for you to follow:

- Please call or email our Customer Support Team, 02 4574 8888 or support@oricom.com.au.
- A Customer Support Team member will verify after troubleshooting with you if your product qualifies under warranty. If so, they will give you a Product Return Authorisation number.
- We will then email a Return Authorisation form and a Repair Notice (if necessary), together with instructions on how to return the product for warranty service.

Please note that if a Customer Support Team member advises that your product does not qualify for return, this warranty does not apply to your product. Products that are authorised to be returned to Oricom in Australia must include all of the following:

- A completed Return Authorisation form
- A copy of your Proof of Purchase (please keep your original copy)
- The faulty product, including all accessories.

EXPRESS WARRANTY 20

Send the approved returns to:
Oricom International Pty Ltd
Locked Bag 658
South Windsor NSW 2756 Australia

Please note that this Express Warranty excludes expenses incurred by you in returning any faulty product to us. You must arrange and pay any expenses incurred (including postage, delivery, freight, transportation or insurance of the product) to return the faulty product to us, however, we will arrange delivery of the repaired or replaced faulty product to you.

Important Information

Repair Notice

Please be aware that the repair of your products may result in the loss of any user-generated data (such as stored telephone numbers, text messages and contact information). Please ensure that you have made a copy of any data saved on your product before sending for repair. Please also be aware that products presented for repair may be replaced by refurbished products or parts of the same type rather than being repaired.

ORICOM CUSTOMER SUPPORT

Oricom have a trained and dedicated team of Customer Support Representatives, each with the knowledge and resources to assist in answering your questions quickly and efficiently.

Oricom Support - Australia

For all product enquiries, troubleshooting or to discuss the range of Oricom products, feel free to contact Oricom or visit our website for answers to frequently asked questions.

(02) 4574 8888

Monday - Friday 8am – 6pm AEST

Email: support@oricom.com.au

www.oricom.com.au

Oricom Support - New Zealand

0800 674 266

Monday - Friday 10am - 8pm NZST

Email: support@oricom.co.nz