




## **WBCR Operating Instructions**

### **Wireless Bike Camera (Rear)**

Keep this user guide for future reference.  
Always retain your proof of purchase in case of warranty service.  
[www.oricom.com.au](http://www.oricom.com.au)

## Device Overview



1. Cover
2. Lens
3. Battery Symbol
4. LED Light (Red)
5. Micro SD Card Slot
6. Type-C Charging Port
7. Power/Wi-Fi On/Off Button
  - Short press to turn on, to turn off press and hold for 4-5 seconds.
  - Wi-Fi On/Off: Default is off, press button once to toggle off/on (button is flashing when on).
8. Battery Level Indicators
9. Lights/Recording Control Button
  - Lights Control: Press & hold button for 4-5 seconds to turn on and cycle through the modes: fast flash, double fast flash, solid on, and off.
  - Recording Control: Short press to toggle between pause and resume recording.
10. Microphone
11. Slider Mount

## Product included list

User Manual x 1	Mounting straps (small) x 3
Bike Cam x 1	Spare adhesive pad x 1
Allen Key x 1	Mounting bracket including adhesive pad x 1
Charging cable x 1	Micro SD card 64GB x 1 (installed in camera)
Mounting straps (large) x 3	

NOTE: only use the supplied SD card in this camera.

## Charging The Device:

1. Using the supplied charging cable, connect 5V, 3Amp power adaptor (not supplied) to the Type-C charging port ⑥ on the device.
2. All four battery level indicators ⑧ are on when the battery is fully charged.

## Connecting the Device and Smart Phone via Wi-Fi:

- 1) Download the App “**DashGo**”



Make sure your Wi-Fi for the Camera is on. Press Button ⑦ once – the LED on the top button should now be flashing – Wi-Fi is now on.

Open your Phone settings and search Wi-Fi Networks.

You should now see OricomCam-xxxx as per below – connect to this Network –

Wi-Fi SSID: OricomCam-xxxx


Password: 12345678

Open the DashGo App to view the cameras video link and access the settings.

Application Icon: 

## Mounting the Device to the Bicycle Seat Post:

1. **Attach the Mount:** Remove the double sided tape backing from the back of the mount and stick in position, then secure the mount to the seat post using the black straps to hold the bracket around the seat post.
2. **Install the Device:** Slide the device downwards onto the mount until you hear a click sound, indicating that it is securely installed.
3. **Adjust and Secure the Angle:** Adjust the device to the proper angle, you can view the camera image on the App to confirm the viewing angle, then tighten the bolt and nut to secure the angle.



## Operating the Device

### 1. Power On/Off

Power On: Short Press the power button ⑦.

Power Off: Press & hold the power button ⑦ for 4-5 seconds again until the device turns off.

### 2. Recording Control

Start/Stop Recording: Short Press the light/recording control button ⑨ to start or stop video recording.

### 3. Wi-Fi On/Off


Toggle Wi-Fi: Press the Power/Wi-Fi button ⑦ once to switch Wi-Fi on or off (the button will start flashing)

### 4. Lights Control

Cycle Light Modes: Press and hold the light/recording control button ⑨ to turn on and cycle through the modes: fast flash, double fast flash, solid on, off.

### 5. Reset

To force the device to shut down and resolve any issues, press the power button ⑦ and the light/recording control button ⑨ simultaneously.



## Product Specification

<b>Item:</b>	WBCR
<b>Dimension:</b>	42.5 x 33.13 x 105mm
<b>Weight:</b>	114.4 g
<b>Mount:</b>	20 g
<b>Lens:</b>	4G
<b>Aperture:</b>	f/1.8
<b>FOV:</b>	Max. 140° (Diagonal) Effective FOV after processing is approx. 113°
<b>Video Resolution:</b>	1920 x 1080p @30fps
<b>Video Format:</b>	MP4
<b>Codec:</b>	H.264
<b>Image Format:</b>	JPG/JPEG
<b>Image Resolution:</b>	1920 x 1080
<b>LED Color:</b>	Red
<b>LED Brightness:</b>	Max. 70 Lumens
<b>Charging Port:</b>	Type-C
<b>Power Input:</b>	DC5V / 3A
<b>Built-in Battery:</b>	3,200mAh Lithium Battery
<b>Memory Card:</b>	Micro SD
<b>Memory Capacity:</b>	Up to 128GB
<b>Wi-Fi Frequency:</b>	2.4 GHz
<b>App:</b>	Supported
<b>Protection:</b>	IP67
<b>Night-time Use</b>	Enhanced low-light performance
<b>G-sensor</b>	When triggered locks current video file to preserve critical footage.

## Express Warranty (Australia)

You are entitled to a replacement product or repair of the product at our discretion according to the terms and conditions of this document if your product is found to be faulty within the Express Warranty Period. This Express Warranty extends to the original purchaser only and is not transferable.

Products distributed by Oricom are manufactured using new materials or new and used materials equivalent to new in performance and reliability. Spare parts may be new or equivalent to new. Spare parts are warranted to be free from defects in material or workmanship for thirty (30) days or for the remainder of the Express Warranty Period of the Oricom branded product in which they are installed, whichever is longer. During the Express Warranty Period, Oricom will where possible repair and if not replace the faulty product or part thereof. All component parts removed under this Express Warranty become the property of Oricom. In the unlikely event that your Oricom product has a recurring failure, Oricom may always, subject to the Competition and Consumer Act 2010, at its discretion, elect to provide you with a replacement product of its choosing that is at least equivalent to your product in performance.

No change to the conditions of this Express Warranty is valid unless it is made in writing and signed by an authorised representative of Oricom.

Oricom will not be liable under this Express Warranty, and to the extent permitted by law will not be liable for any defect, loss, damage or injury arising out of or in connection with a:

1. Failure by you to adhere to the warnings and follow the instructions set out in this user guide for the proper installation and use of the product;
2. Wilful misconduct or deliberate misuse by you of the product;
3. Any external cause beyond our control, including but not limited to power failure, lightning or over voltage; or
4. Modification to the product or services carried out on the product by anyone other than Oricom or Oricom's authorised service provider.

## How to make a claim under your Express Warranty in Australia

Oricom has a simple warranty process for you to follow:

- Please call or email our Customer Support Team, (02) 4574 8888 or support@oricom.com.au.
- A Customer Support Team member will verify after troubleshooting with you if your product qualifies under warranty. If so, they will give you a Product Return Authorisation number.
- We will then email or fax a Return Authorisation form and a Repair Notice (if necessary), together with instructions on how to return the goods for warranty service.

Please note that if a Customer Support Team member advises that your product does not qualify for return, this warranty does not apply to your product. Products that are authorised to be returned to Oricom in Australia must include all of the following:

- A completed Return Authorisation form
- A copy of your Proof of Purchase (please keep your original copy)
- The faulty product, including all accessories.

Send the approved returns to:

Oricom International Pty Ltd  
Locked Bag 658  
South Windsor NSW 2756 Australia

Please note that this Express Warranty excludes expenses incurred by you in returning any faulty product to us. You must arrange and pay any expenses incurred (including postage, delivery, freight, transportation or insurance of the product) to return the faulty product to us, however, we will arrange delivery of the repaired or replaced faulty product to you.

## Important Information

### Repair Notice

Please be aware that the repair of your goods may result in the loss of any user generated data (such as stored telephone numbers, text messages and contact information). Please ensure that you have made a copy of any data saved on your goods before sending for repair. Please also be aware that goods presented for repair may be replaced by refurbished goods or parts of the same type rather than being repaired.



# ORICOM CUSTOMER SUPPORT

Oricom have a trained and dedicated team of Customer Support Representatives, each with the knowledge and resources to assist in answering your questions quickly and efficiently.

## **Oricom Support - Australia**

For all product enquiries, troubleshooting or to discuss the range of Oricom products, feel free to contact Oricom or visit our website for answers to frequently asked questions.

**(02) 4574 8888**

Monday - Friday 8am - 6pm AEST

Email: [support@oricom.com.au](mailto:support@oricom.com.au)

[www.oricom.com.au](http://www.oricom.com.au)

## **Oricom Support - New Zealand**

**0800 674 266**

Monday - Friday 10am - 8pm NZST

Email: [support@oricom.co.nz](mailto:support@oricom.co.nz)

