



### **WARNING THIS PRODUCT CONTAINS A BUTTON/COIN CELL BATTERY**

Button/coin cell batteries are hazardous and must be kept out of reach of children at all times, whether the battery is new or used. These batteries can cause severe or fatal injuries in 2 hours or less if swallowed or placed inside any part of the body. If it is suspected a button/coin cell battery has been swallowed or placed inside any part of the body, seek medical attention immediately or contact the Australian Poisons Information Centre on 131126 for 24/7 fast, expert advice.

## User Guide

### **PLEASE READ THIS USER GUIDE BEFORE INITIAL USE, AND MUST BE RETAINED FOR FUTURE REFERENCE.**

The Oricom Digital Bath & Room Thermometer is designed to monitor the temperature of baby's bath or room and to use as a fun bath toy for babies of all ages.

#### **Using your Oricom Bath or Room Thermometer**

Ideal bathwater temperatures should be between 36.5°C and 38°C. A temperature higher than 39°C may cause scalds or burns.

- This thermometer measures water temperature between 0°C and 50°C.
- To activate, gently tap the bath thermometer to turn on.
- Wait 10 seconds, the digital screen will display temperature when the thermometer is on and ready for operation.
- Place the thermometer in bath water as the tub is being filled. Mix the water thoroughly whilst taking the temperature.
- Temperature alert function – LED light illuminates when water temperature is 39°C or over.
- Auto shut-off after 30 mins to save battery power.
- The thermometer will continue to re-check and adjust to show ambient room or water temperature every 10 seconds when turned on.

#### **Remove & Install Silicone Cover**

- To remove the silicone cover, first loosen the 4 tabs ① and then remove the silicone cover ②.
- To install the silicone cover, first put on the silicone cover and then fix the 4 tabs in the holes ③.

\* Make sure all parts are dry before installing the silicone cover.



**CAUTION: Always check water temperature manually in addition to using this thermometer. Never leave children unattended in the bathroom. There is no substitute for proper adult supervision.**


## Battery Safety

\* **WARNING – THIS PRODUCT CONTAINS ALKALINE BUTTON BATTERIES, KEEP OUT OF REACH OF CHILDREN.**

- If you suspect your child has swallowed or inserted a button battery, **immediately take them to a hospital emergency room**. Do not give any food or water. If you find the battery has leaked fluid please do not touch the battery or fluid. Dispose of the battery properly do not wrap in metal or aluminum foil, wrap in newspaper and dispose of carefully. Battery may explode if burnt or exposed to excessive heat. Check your product regularly for damage and an exhausted battery. Make sure there are no loose batteries within any child's reach.
- Swallowing may lead to serious injury in as little as 2 hours or death, due to chemical burns and potential perforation of the oesophagus.
- As well as attending hospital or seeing an emergency doctor, contact the 24-hour Poisons Information Centre on 13 11 26 for additional treatment information. Examine devices and make sure the battery compartment is correctly secured.
- Dispose of used button batteries immediately and safely. Flat batteries can still be dangerous.
- Tell others about the risk associated with button batteries and how to keep their children safe.

## How to Replace the Battery

- Remove the silicone cover.
- Remove the battery cover on the back of the thermometer module, push-down the lock pin ① and turn the battery cover ② counterclockwise using a coin.
- Remove the old battery from the battery compartment.
- Insert a new CR2032 battery in the direction with the (+) polarity facing up.
- Put the battery cover back on, push-down the lock pin ③ and turn the battery cover ④ until the locking pin is in place and the two round markings line up as per images to the right.



**CAUTION: This product is only to be used in water when assembled and operated in accordance with the instructions. If the battery cover is not fitted correctly then the seal will not be water proof and water will enter the product and result in damage.**

**Batteries represent a hazard to health and the environment!**

- They contain toxic, ecologically hazardous heavy metals. Do not dispose of batteries in a fire as they may explode. Dispose of batteries according to local regulations, never in your household rubbish.
- Do not dismantle, cut, open, crush, bend, puncture, or shred cells or batteries. If a battery leaks, do not let the battery liquid touch skin or eyes. If this happens, immediately flush the affected areas with water, and seek medical assistance.
- Do not modify, remanufacture, and attempt to insert foreign objects into the battery, or immerse or expose it to water or other liquids. Batteries may explode if damaged. Always remove exhausted batteries from the product.
- Use only the same type of battery supplied with the product. Improper use or use of unapproved batteries may present a risk of fire, explosion, or other hazard, and may invalidate any approval or warranty.
- If you believe the batteries are damaged stop using the product. Contact Oricom for assistance. Never use a damaged battery.

## Need help?

If you need assistance setting up or using your Thermometer call the Oricom Support team on (02) 4574 8888.

## **Express Warranty (Australia)**

This Express Warranty is provided by Oricom International Pty Ltd ABN 46 086 116 369, Unit 1, 4 Sovereign Place, South Windsor NSW 2756, herein after referred to as "Oricom".

Oricom warrants that the product is free from defects in materials or workmanship during the Express Warranty Period. This Express Warranty does not extend to any product from which the serial number has been removed or was purchased outside of Australia.

The benefits of this Express Warranty are in addition to other rights and remedies you may have under the Australian Consumer Law. Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure. In the event of a minor failure, Oricom reserves the right to choose to repair or replace the product.

The Express Warranty Period will be a period of 12 months beginning on the date of purchase of the product evidenced by your dated sales receipt. You are required to provide proof of purchase as a condition of receiving Express Warranty services.

You are entitled to a replacement product or repair of the product at our discretion according to the terms and conditions of this document if your product is found to be faulty within the Express Warranty Period. This Express Warranty extends to the original purchaser only and is not transferable.

Products distributed by Oricom are manufactured using new materials or new and used materials equivalent to new in performance and reliability. Spare parts may be new or equivalent to new. Spare parts are warranted to be free from defects in material or workmanship for thirty (30) days or for the remainder of the Express Warranty Period of the Oricom branded product in which they are installed, whichever is longer. During the Express Warranty Period, Oricom will where possible repair and if not replace the faulty product or part thereof. All component parts removed under this Express Warranty become the property of Oricom. In the unlikely event that your Oricom product has a recurring failure, Oricom may always, subject to the Competition and Consumer Act 2010, at its discretion, elect to provide you with a replacement product of its choosing that is at least equivalent to your product in performance.

No change to the conditions of this Express Warranty is valid unless it is made in writing and signed by an authorised representative of Oricom.

Oricom will not be liable under this Express Warranty, and to the extent permitted by law will not be liable for any defect, loss, damage or injury arising out of or in connection with a:

1. Failure by you to adhere to the warnings and follow the instructions set out in this user guide for the proper installation and use of the product;
2. Willful misconduct or deliberate misuse by you of the product;
3. Any external cause beyond our control, including but not limited to power failure, lightning or over voltage; or
4. Modification to the product or services carried out on the product by anyone other than Oricom or Oricom's authorised service provider.

## How to make a claim under your Express Warranty in Australia

Oricom has a simple warranty process for you to follow:

- Please call or email our Customer Support Team, 02 4574 8888 or [support@oricom.com.au](mailto:support@oricom.com.au).
- A Customer Support Team member will verify after troubleshooting with you if your product qualifies under warranty. If so, they will give you a Product Return Authorisation number.
- We will then email a Return Authorisation form and a Repair Notice (if necessary), together with instructions on how to return the product for warranty service.

Please note that if a Customer Support Team member advises that your product does not qualify for return, this warranty does not apply to your product. Products that are authorised to be returned to Oricom in Australia must include all of the following:

- A completed Return Authorisation form
- A copy of your Proof of Purchase (please keep your original copy)
- The faulty product, including all accessories.

Send the approved returns to:

Oricom International Pty Ltd  
Locked Bag 658  
South Windsor NSW 2756 Australia

Please note that this Express Warranty excludes expenses incurred by you in returning any faulty product to us. You must arrange and pay any expenses incurred (including postage, delivery, freight, transportation or insurance of the product) to return the faulty product to us, however, we will arrange delivery of the repaired or replaced faulty product to you.

### Important Information - Repair Notice

Please be aware that the repair of your products may result in the loss of any user-generated data (such as stored telephone numbers, text messages and contact information). Please ensure that you have made a copy of any data saved on your product before sending for repair. Please also be aware that products presented for repair may be replaced by refurbished products or parts of the same type rather than being repaired.

Contact Details for Oricom support and Warranty claims in Australia

Oricom International Pty Ltd  
Unit 1, 4 Sovereign Place  
South Windsor, NSW 2756  
Australia

Email: [support@oricom.com.au](mailto:support@oricom.com.au)

Phone: (02) 4574 8888

(Monday to Friday 8am to 6pm AEST)

Web: [www.oricom.com.au](http://www.oricom.com.au)