



Baby Monitor SECURE55



User Guide

KEEP THIS USER GUIDE FOR FUTURE REFERENCE

Always retain your proof of purchase in case of warranty service and register your product on line at:

AUSTRALIA: www.oricom.com.au NEW ZEALAND: www.oricom.co.nz



TABLE OF CONTENTS

IMPORTANT SAFETY INFORMATION	1
GETTING STARTED	3
ORICOM DIGITAL BABY MONITOR	6
SETTING UP	7
USING YOUR DIGITAL BABY MONITOR.....	10
TROUBLESHOOTING.....	12
CUSTOMER SUPPORT	14
EXPRESS WARRANTY (AUSTRALIA).....	15

Need Help?

If you need assistance setting up or using your Oricom product now or in the future, call Oricom Support.

Australia 1300 889 785 or (02) 4574 8888

www.oricom.com.au

Mon-Fri 8am – 6pm AEST

New Zealand 0800 67 42 66

www.oricom.co.nz

Mon-Fri 10am – 8pm NZST





IMPORTANT SAFETY INFORMATION

1

Important Safety Information

- It is very important that you read the User Guide carefully as it contains detailed information you will need to get the most from your Oricom Baby Monitor. If you have any issues setting up or using your Oricom Baby monitor please call our Customer support team. Our dedicated local team are more likely to be able to help you than the retailer where you made your purchase.
- Your Oricom Baby Monitor is designed to be an aid and should not be used as a substitute for responsible and proper adult supervision of a child.
- The Baby Monitor has been designed to provide some added reassurance in the form of sound transmission for those times when you are not in the same room as your baby provided you always stay within hearing range of the baby monitor during use. Your Baby Monitor is not a medical device, nor a device to prevent cases of Sudden Infant Death Syndrome (SID'S) or "cot death", and you should not rely on it for your baby's wellbeing. It is important that you regularly check on your baby personally.
- Make sure the Baby unit, Parent unit and mains adaptor cables are kept out of reach of your baby and other young children at all times, at least one metre away.
- Never place the baby unit or parent unit inside your baby's cot, bed or playpen.
- Never cover the Parent or baby units with clothes, towels or blankets or any other item. Never use or place your Parent or Baby unit in or near moisture or water (e.g. near bath or pool). Immersing in water could cause electric shock and even death.
- The installation location plays an important role in ensuring proper operation. Therefore, maintain a distance of at least one meter from other electronic equipment, such as microwave ovens or hi-fi

devices, otherwise they could cause interference. During continual use the Baby unit power adaptors may become warm to the touch. This is normal and should not be a concern.

Warning

Risk of suffocation!

Keep all packaging materials and protective foils out of reach of children.

Do not place the AC Adaptor cable in a high "wear and tear" location. Never use a frayed or compromised cord.

Battery safety

- Batteries represent a hazard to health and the environment!
- They contain toxic, ecologically hazardous heavy metals. Do not dispose of batteries in a fire as they may explode. Dispose of batteries according to local regulations, never in your household rubbish.
- Do not dismantle, cut, open, crush, bend, puncture,

or shred cells or batteries. If a battery leaks, do not let the battery liquid touch skin or eyes. If this happens, immediately flush the affected areas with water, and seek medical assistance.

- Do not modify, remanufacture, attempt to insert foreign objects into the battery, or immerse or expose it to water or other liquids. Batteries may explode if damaged.
- Use only the batteries supplied with the product. Improper use, or use of unapproved batteries may present a risk of fire, explosion, or other hazard, and may invalidate any approval or warranty.
- If you believe the batteries are damaged, remove product from the charger and stop using the product. Contact Oricom for assistance. Never use a damaged battery.

Disposal

- Always dispose of your products at the end of their life in accordance with your local waste disposal requirements. Packaging materials all cardboard and paper packaging should be recycled in accordance with your local council waste regulations.

This User Guide provides you with all the information you need to get the most from your Oricom Digital Baby Monitor.

Please read this guide carefully and keep it for future reference.

Need help?

If you need assistance setting up or using your Oricom Digital Baby Monitor call our Support team on 1300 889 785. If you would like any additional or replacement rechargeable batteries for the parent unit (Part No. BAT550MAH) order online at www.oricom.com.au.

Our dedicated advisors are more likely to be able to help you than the retailer where you made your purchase.

Alternatively, you may find the answer in the 'help' section at the back of this guide.

Additional answer to Frequently Asked Questions are also available from www.oricom.com.au

Got everything?

Baby unit


- Parent unit
- 2 X AAA NiMH 550mAh rechargeable batteries for Parent unit
- 2 X power adaptors
- User Guide

4

GETTING TO KNOW YOUR SC55

Getting to know your SC55

Parent Unit




1. Talk- Press to talk to your baby
2. Power on/ off - Press and hold to switch the power on or off
3. Volume down(-) - Decrease speaker volume
4. Power Socket - for connection to the mains power socket via the power adaptor supplied
5. Volume up (+) - Increase speaker volume
6. Speaker
7. Microphone
8. Indicator Lamp - Indicates the power and link status of the parent unit
9. VOX switch - To turn the VOX function on or off. See page 11 for further information
10. Baby sound level LEDs - Indicates the level of received sound. The LEDs will light up progressively as the sound increases. See page 15 for further information.
11. Battery cover

GETTING TO KNOW YOUR SC55

5

Getting to know your SC55

Baby Unit



12. Search function
13. Indicator Lamps - Indicates the link status of the baby unit
14. Power on/ off - Press and hold to switch the power on or off
15. Volume down (-) - Decrease speaker volume
16. Night light - Press to switch the night light on or off
17. Microphone
18. Volume up (+) - Increase speaker volume
19. Power Socket - For connection to the mains power socket via the power adaptor supplied
20. Speaker
21. Rechargeable batteriesx2
22. Power adaptor cablex2



6

ORICOM DIGITAL BABY MONITOR

Parent Unit

1. Remove the battery cover from the rear of the parent unit. Insert the 2 x AAA batteries (supplied) observing the polarity instructions in the battery compartment. Replace the battery cover.
2. Plug one of the power adaptor cables into the socket marked 'DC6V 500mA' on the top of the parent unit. Plug the other end into the mains power wall socket. The indicator lamp on the parent unit will flash red to indicate the unit is charging.
3. Leave the batteries to charge for 16 hours to reach maximum charge.
4. To turn on the parent unit, press and hold the power button. The parent unit will beep until the baby unit is detected. To stop the unit beeping, press and hold the power button to turn the unit off, or turn baby unit on.

Warning

Only use the power adaptors supplied. Using an incorrect power adaptor may permanently damage your product. This product is designed for indoor use only.

Battery Performance

Rechargeable batteries in the parent unit will last up to 8 hours in normal use. Please note that new batteries do not reach full capacity until they have been in normal use for several days.

The charge capacity of rechargeable batteries will reduce with time as they wear out, so reducing the performance time of the parent unit. Eventually they will need to be replaced. New batteries can be obtained from Oricom.

www.oricom.com.au or 1300 889 785.

The parent unit rechargeable batteries will lose charge over a period of time, even if switched off.

Battery Low Warning

When the batteries are low the parent unit will emit a low battery alert and the low battery indicator on the unit will turn red. Place the parent unit back on the charger to charge the batteries. To speed up the charging process, turn the parent unit off when

charging if it is not being used.

You can still use the parent unit to monitor your baby even when the batteries are low, provided it remains connected to the charger to re-charge the batteries.

Replacing the Batteries

To replace the batteries, simply remove the battery cover on the parent unit and remove the batteries. Ensure new batteries are inserted observing the polarity indicators in the battery compartment.

- Only use rechargeable NiMH 1.2V, 550mAh AAA batteries. Do not use alkaline batteries in this unit.
- Do not mix used batteries with new batteries.
- Remove the batteries when the appliance is unused for a long period of time.
- Remove the power adaptor before replacing batteries.

Baby Unit

1. Plug the remaining power adaptor into the socket on the baby unit labelled DC6V 500mA.
2. Thread the cable through the cable clips on the rear of the unit to hold the charger cable in place.
3. Plug the end of the charger cable into the mains power and switch on.
4. To turn on the baby unit, press and hold the power button. The green indicator lamp will flash until the parent unit is detected.

Starting Up

1. Power on the parent and baby units by pressing and holding the power button.
2. The green indicator lamp will flash on both units whilst the connection is being established.
3. Once the parent unit and the baby unit are linked, the indicator lamp will become a solid green light.

NOTE: The indicator lamp on the parent unit will continue to flash red whilst it is on charge, after the link has been established.

If the link is broken:

- Check that the mains power is plugged in and switched on at the baby unit
- Check that both units are powered on
- Check that the batteries are charged in the parent unit
- Check that the parent and baby units are within range of each other (in ideal conditions the range is up to 300 metres outdoors and 50 metres indoors)

IMPORTANT

The link confirmation between the two units is vital for use so they can communicate. If the link between the units is broken at any time, the indicator lamps will flash green on the parent and baby units as they try to search for each other. After 30 seconds, if the link is still broken, an alert tone will sound on the parent unit until the link is re-established.

Positioning Your Units

The baby unit should ideally be within 1m-2m of your baby for best performance.

If you place the parent unit and baby unit too close together you will hear a high pitched noise (feedback); this is normal. The units are designed to be located at a distance from one another e.g. in separate rooms. If you experience feedback, increase the distance between the units, or turn down the volume of the parent unit.



10

USING YOUR DIGITAL BABY MONITOR

Switching On/Off

Switch the baby unit on

Press and hold the power button on the baby unit for 3 seconds. The green link indicator will flash until it links with the parent unit. Once linked, the green link indicator will remain on.

Switch the parent unit on

Press and hold the power button on the parent unit for 3 seconds. The green link indicator will flash. Once the units are linked the green link indicators on the parent and baby units will stop flashing and remain a steady green. The units are now ready to use.

Switch the baby unit off

Press and hold the power button on the baby unit for 3 seconds. The green link indicator will switch off.

Switch the parent unit off

Press and hold the power button on the parent unit for 3 seconds. The green link indicator will switch off.

Adjusting the Volume


To adjust the volume, press the volume up (+) or volume down (-) buttons on the parent or baby unit. There are 10 sound levels. Each sound level is signalled by a beep. When maximum or minimum volume has been reached, the unit will beep 3 times.

Baby Sound Level LED Indicators

The three LEDs on the left of the parent unit indicate the level of sound being received by the baby unit. The LEDs light up progressively as the sound increases.



Talk Back



You can use the parent unit Talk Back feature as a one way intercom to comfort and reassure your baby. Press and hold down the 'Talk' button on the parent unit to talk to your baby. By speaking into the parent unit your baby will hear your voice through the baby unit. Please note that when using Talk Back you will not be able to hear your baby until you release the 'Talk' button. When using Talk Back, hold the parent unit approximately 30cm in front of your mouth whilst speaking.

Nightlight

You can set a comforting nightlight on the baby unit.
- To switch the nightlight on or off press the nightlight button on the baby unit.


The baby unit must be switched on for the nightlight to work, but need not be linked to the parent unit.

Search

The search function allows you to locate the parent unit from the baby unit. When the parent and baby units are linked, press the search button for one second to activate the search function. The parent unit will emit a double beep at 2 second intervals to assist in locating the unit. To turn off the alert, press any button on the parent unit. If no button is pressed after 2 minutes, the alert will automatically stop.

VOX

When the VOX function is turned on, the parent unit will be activated when a certain noise level is reached (the first sound level LED). This means that low level sounds will not be heard through the parent unit. When the VOX function is turned off, lower level sounds are transmitted to the parent unit.

1. To turn the VOX function 'on', slide the VOX button to 'on' on the parent unit.
 2. To turn the VOX function 'off', slide the VOX button to 'off' on the parent unit.
- 

Should you experience difficulties operating your SC55 please refer to the troubleshooting guide below. If you still experience difficulties please contact Oricom Customer Support on 1300 889 785 for assistance.

Troubleshooting

Issue	Possible Solution
Parent unit not functioning	<ul style="list-style-type: none">• Check batteries are inserted correctly in the parent unit as per the user guide.• Check the correct batteries are being used.• Check the batteries are charged.• Check the power cable is connected correctly and the power outlet is turned on.• Check the unit is turned on by holding down the power button.
Baby unit not functioning	<ul style="list-style-type: none">• Check the power cable is connected correctly and the power outlet is turned on.• Check the unit is turned on by holding down the power button.• Check baby unit is within 1-2metres of baby.



TROUBLESHOOTING

13

Issue	Possible Solution
Green light flashing on either unit	<ul style="list-style-type: none">• The units are not linked. Check both units are turned on.• The units are out of range. Bring both units closer together until light stops flashing.
Parent unit is beeping	<ul style="list-style-type: none">• If LED light on parent unit is red, the unit needs charging. Connect charger.• If LED light on parent unit is green, the unit is out of range. Bring it closer to the baby unit.
Parent unit remains silent	<ul style="list-style-type: none">• Increase the volume on the parent unit.• VOX may be turned on. Turn this feature off.
High pitched noise through parent unit	<ul style="list-style-type: none">• Increase the distance between the baby and parent units.• Reduce the volume on the parent unit.
Talkback feature not working	<ul style="list-style-type: none">• Ensure the baby unit is turned on.• Increase the volume on the baby unit.



14

CUSTOMER SUPPORT

Customer Support

If you have any problems setting up or using this product you will find useful tips and information in the Troubleshooting section of this user guide as well as “Frequently Asked Questions” on our website www.oricom.com.au.

If you have further questions about using the product after reviewing the resources above or would like to purchase replacement parts or accessories please call our Customer Support Team. Our dedicated local support team are more likely to be able to help you than the retailer where you made your purchase.

Important

Please retain your purchase receipt and attach to the back page of this user guide as you will need to produce this if warranty service is required. Take a few moments to register your product online: www.oricom.com.au





EXPRESS WARRANTY (AUSTRALIA)

15

Express Warranty (Australia)

This Express Warranty is provided by Oricom International Pty Ltd ABN 46 086 116 369, Unit 1, 4 Sovereign Place, South Windsor NSW 2756, herein after referred to as "Oricom".

Oricom products come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure. Oricom warrants that the product is free from defects in materials or workmanship during the Express Warranty Period. This Express Warranty does not extend to any product from which the serial number has been removed or was purchased outside of Australia.

Nothing in this Express Warranty excludes, restricts or modifies any condition, warranty, guarantee, implied term, right or remedy pursuant to the Australian Consumer Law and which may not be so excluded, restricted or modified. For such conditions, terms, guarantees and warranties that cannot be excluded, restricted or modified, Oricom limits the remedies available to extent permitted in the relevant legislation. The Express Warranty Period will be 3 years from the date of purchase of the product evidenced by your dated sales receipt. You are required to provide proof of purchase as a condition of receiving Express Warranty services.

You are entitled to a replacement product or repair of the product at our discretion according to the terms and conditions of this document if your product is found to be faulty within the Express Warranty Period.

This Express Warranty extends to the original purchaser only and is not transferable.





16

EXPRESS WARRANTY (AUSTRALIA)

Products distributed by Oricom are manufactured using new materials or new and used materials equivalent to new in performance and reliability. Spare parts may be new or equivalent to new. Spare parts are warranted to be free from defects in material or workmanship for thirty (30) days or for the remainder of the Express Warranty Period of the Oricom branded product in which they are installed, whichever is longer.

During the Express Warranty Period, Oricom will where possible repair and if not replace the faulty product or part thereof. All component parts removed under this Express Warranty become the property of Oricom. In the unlikely event that your Oricom product has a recurring failure, Oricom may always, subject to the Competition and Consumer Act 2010, at its discretion, elect to provide you with a replacement product of its choosing that is at least equivalent to your product in performance.

No change to the conditions of this Express Warranty is valid unless it is made in writing and signed by an authorised representative of Oricom.

Oricom will not be liable under this Express Warranty, and to the extent permitted by law will not be liable for any defect, loss, damage or injury arising out of or in connection with a:

1. Failure by you to adhere to the warnings and follow the instructions set out in this user guide for the proper installation and use of the product;
2. Wilful misconduct or deliberate misuse by you of the product;
3. Any external cause beyond our control, including but not limited to power failure, lightning or over voltage; or
4. Modification to the product or services carried out on the product by anyone other than Oricom or Oricom's authorised service provider.





EXPRESS WARRANTY (AUSTRALIA)

17

How to make a claim under your Express Warranty in Australia

Oricom has a simple warranty process for you to follow:

- Please call or email our Customer Support Team, 1300 889 785 or support@oricom.com.au.
- A Customer Support Team member will verify after troubleshooting with you if your product qualifies under warranty. If so, they will give you a Product Return Authorisation number.
- We will then email or fax a Return Authorisation form and a Repair Notice (if necessary), together with instructions on how to return the goods for warranty service.

Please note that if a Customer Support Team member advises that your product does not qualify for return, this warranty does not apply to your product. Products that are authorised to be returned to Oricom in Australia must include all of the following:

- A completed Return Authorisation form
- A copy of your Proof of Purchase (please keep your original copy)
- The faulty product, including all accessories.

Send the approved returns to:

Oricom International Pty Ltd
Locked Bag 658
South Windsor NSW 2756 Australia





18

EXPRESS WARRANTY (AUSTRALIA)

Please note that this Express Warranty excludes expenses incurred by you in returning any faulty product to us. You must arrange and pay any expenses incurred (including postage, delivery, freight, transportation or insurance of the product) to return the faulty product to us, however, we will arrange delivery of the repaired or replaced faulty product to you.







Contact Details for Oricom Support and Express Warranty Claims in Australia

Oricom International Pty Ltd

Locked Bag 658

South Windsor, NSW 2756

Australia

Email: support@oricom.com.au

Phone: 1300 889 785 or (02) 4574 8888

(Monday to Friday 8am to 6pm AEST)

Web: www.oricom.com.au

Fax: (02) 4574 8898

Contact Details for Oricom Support and Express Warranty Claims in New Zealand

Email: support@oricom.co.nz

Phone: 0800 674 266

(Monday to Friday 10am to 8pm NZST)

Web: www.oricom.co.nz



Ref: 12102015

