



## Vibrating Alarm Clock

VAC500

Keep this user guide for future reference. Always retain your proof of purchase in case of warranty service and register your product on line at: AUSTRALIA: [www.oricom.com.au](http://www.oricom.com.au)

## Table of contents

---

Getting Started .....	3
Feature Identifications .....	4
Operation.....	5
Specifications .....	7
Customer Support.....	8
Warranty.....	9

### **Need Help?**

If you need assistance setting up or using your Oricom product now or in the future, call Oricom Support.

Australia      1300 889 785  
                    [www.oricom.com.au](http://www.oricom.com.au)  
                    Mon-Fri 8am – 6pm AEST

New Zealand    0800 67 42 66  
                    [www.oricom.co.nz](http://www.oricom.co.nz)  
                    Mon-Fri 10am – 8pm NZST

Thank you for selecting the Oricom VAC500, vibrating alarm clock. The VAC500's powerful sound and vibration is designed to wake-up even the heaviest sleeper.

## Package Content

VAC500 Vibrating alarm clock



Pillow clip



Adaptor

## Battery installation

Install three AA alkaline batteries (not included).

Please observe correct battery polarity while installing.

A set of brand new alkaline batteries will last about six to eight months of normal usage.

Please replace batteries if you notice the shaker is weak or if the back-light is dim.

## Battery Safety and Disposal

Please do not dispose of used batteries in the household rubbish.

Please check your local government regulations for proper disposal.

## Feature Identifications

---



1. Built-in flashlight
2. Alarm mode switch (audio + shaker, shaker, audio, off)
3. MODE (alarm, timer, temperature)
4. SET to select setting choice
5. SNOOZE
6. UP
7. DN/TEST (down or test)
8. Audio alarm tone control (Hi-Med-Lo)
9. Audio alarm volume control (Hi-Med-Lo)
10. Battery Compartment (rear)
11. Power Jack
12. Back light ON/OFF switch

## Operation

### 1. To set time

1. Press and hold SET for 2 seconds
2. Press UP to display AM, PM, 12 or 24-hour clock; press SET to select
3. Press UP or DN to set the Hour, press SET to select. Repeat these steps to set Minute.

### 2. To set alarm time & snooze

1. Press MODE to go to Alarm mode, press and hold SET for 2 seconds to select
2. Press UP or DN to set the alarm hour, press SET to select.  
Repeat these steps to set Minute.
3. While SNOZ is flashing, press SET to turn on the snooze function or press UP to turn it off. It will automatically return to the normal clock mode after about 5 seconds.
4. If SNOOZE function is on -- when the alarm sounds, the alarm will continue for 40 seconds and then stop. If the SNOOZE button is pushed any time while the alarm is sounding, the alarm will stop immediately but it will sound again in eight minutes. You can repeat this cycle for up to seven times. To stop the alarm completely any time, press any button other than the SNOOZE button on top of the clock.
5. If SNOOZE function is off --- when the alarm sounds, pressing the SNOOZE button will stop the alarm completely.

### 3. To set alarm on/off & alarm mode

1. Slide the switch to OFF to disable the alarm or to stop the on-going alarm action.
2. Slide the switch to AUDIO, SHAKER or ALL (audio + shaker) to select your alarm mode and to set the Alarm On.

### **4. To test your alarm setting**

1. Press and hold TEST for 3 seconds, the alarm is triggered for a period of 10 seconds and then returns to the clock mode.

### **5. To use clock as a Timer**

1. Press MODE to go to the Timer mode, press and hold SET for 2 seconds to select.
2. Press UP or DN to set the desired hour setting, press SET to select. Repeat these steps to set the desired minute setting.
3. Press DN to start/stop the timer count-down, (if DN is not pressed within five seconds clock will return to regular timekeeping mode.)
4. When the set time expires, the alarm will sound-off (same alarm mode as the alarm clock setting) for 30 seconds (unless stopped by pressing any of the top keys).

### **6. To show the room temperature**

1. Press MODE to go to the Thermometer mode, the room temperature appears.
2. If needed, press UP to set reading in C or F.
3. Press MODE to return to the clock mode.

### **7. To turn ON/OFF back light**

1. Connect adaptor.
2. Move back light ON/OFF switch in the battery compartment to ON or OFF.

## Specifications

Functions	clock, alarm clock, timer, thermometer and flash-light
Clock modes	12 or 24 hours
Alarm modes	audio, vibration, audio & vibration
Thermometer modes	C or F
Size	118 x 71 x 27 mm; 4.6 x 2.8 x 1.1 inches
Weight (without batteries)	140 gm; 5 oz.
Power supply	3 AA alkaline batteries (not supplied)
Battery life	6-8 months of normal use
Vibration	8200+-RPM at 0.21A
Flasher brightness	2000 mcd
Adaptor	INPUT (100-240V 50/60Hz 0.3A) OUT (5V--600mA)

### **Customer Support**

If you have any problems setting up or using this product you will find useful tips and information in the Troubleshooting section of this user guide as well as "Frequently Asked Questions" on our website [www.oricom.com.au](http://www.oricom.com.au).

If you have further questions about using the product after reviewing the resources above or would like to purchase replacement parts or accessories please call our Customer Support Team. Our dedicated local support team are more likely to be able to help you than the retailer where you made your purchase.

### **Important**

Please retain your purchase receipt and attach to the back page of this user guide as you will need to produce this if warranty service is required. Take a few moments to register your product online: [www.oricom.com.au](http://www.oricom.com.au)

### **How to make a claim under Warranty in Australia**

Oricom has a simple warranty process for you to follow:

- Please call or email our Customer Support Team, contact details follow.
- A Customer Support Team member will verify after troubleshooting with you if your product qualifies under warranty. If so, they will give you a Product Return Authorisation number.
- We will then email or fax a Return Authorisation form and a Repair Notice (if necessary), together with instructions on how to return the goods for warranty service.

Please note that if a Customer Support Team member advises that your product does not qualify for return, this warranty does not apply to your product.

Products that are authorised to be returned to Oricom in Australia must include all of the following:

- A completed Return Authorisation form
- A copy of your Proof of Purchase (please keep your original copy)
- The faulty product, including all accessories.

Send the approved returns to:

Oricom International Pty Ltd  
Locked Bag 658  
South Windsor NSW 2756 Australia

Please note that this warranty excludes expenses incurred by you in returning any faulty product to us. You must arrange and pay any expenses incurred (including postage, delivery, freight, transportation or insurance of the product) to return the faulty product to us, however, we will arrange delivery of the repaired or replaced faulty product to you.

### **Important Information**

#### **Repair Notice**

Please be aware that the repair of your goods may result in the loss of any user-generated data (such as stored telephone numbers, text messages and contact information). Please ensure that you have made a copy of any data saved on your goods before sending for repair.

Please also be aware that goods presented for repair may be replaced by refurbished goods or parts of the same type rather than being repaired.

### Warranty Information (Australia)

This Warranty is provided by Oricom International Pty Ltd ABN 46 086 116 369, Unit 1, 4 Sovereign Place, South Windsor NSW 2756, herein after referred to as "Oricom".

Oricom makes no other warranties or conditions, express or implied, including as to acceptable quality and fitness for a particular purpose, except as stated in this Warranty.

Any implied warranties that may be imposed by law are limited in duration to the Warranty Period.

Oricom warrants that the product is free from defects in materials or workmanship during the Warranty Period. This Warranty does not extend to any product from which the serial number has been removed or was purchased outside of Australia.

This warranty in no way affects your statutory warranty rights under the Competition and Consumer Act 2010 or any other similar legislation.

The Warranty Period will be 1 year from the date of purchase of the product evidenced by your dated sales receipt. You are required to provide proof of purchase as a condition of receiving warranty services.

You are entitled to a replacement product or repair of the product according to the terms and conditions of this document if your product is found to be faulty within the Warranty Period. This Warranty extends to the original purchaser only and is not transferable.

Rechargeable battery cells and rechargeable battery packs (if supplied) with this product are covered under this warranty for a period of 90 days.

Products distributed by Oricom are manufactured using new materials or new and used materials equivalent to new in performance and reliability. Spare parts may be new or equivalent to new. Spare parts are warranted to be free from defects in material or workmanship for thirty (30) days or for the remainder of the Warranty Period of the Oricom branded product in which they are installed, whichever is longer. During the Warranty Period, Oricom will where possible repair and if not replace the faulty product or part thereof. All component parts removed under this Warranty become the property of Oricom. In the unlikely event that your Oricom product has a recurring failure, Oricom may, subject to the Competition and Consumer Act 2010, at its discretion, elect to provide you with a replacement product of its choosing that is at least equivalent to your product in performance.

Oricom does not warrant that the operation of the product will be uninterrupted or error free.

Oricom is not responsible for damage that occurs as a result of your failure to follow the instructions that came with the product. These terms and conditions together with any specific terms and conditions contained in the user guide to the product purchased constitute the complete and exclusive agreement between you and Oricom regarding the product.

No change to the conditions of this Warranty is valid unless it is made in writing and signed by an authorised representative of Oricom.

Oricom will not be in breach of a warranty expressly set out in this User Guide or under the Competition and Consumer Act 2010 and excludes any liability for damages or any other remedy arising under any other legislation or the common law if the damage occurs as a result of:

1. failure by you to adhere to the warnings and follow the instructions set out in this user guide for the proper installation and use of the product;
2. negligence on your part or misuse by you of the product;
3. an uncontrollable external cause which results in the product not functioning including but not limited to power failure, lightning or over voltage; and
4. modification to the product or services carried out on the production by anyone other than Oricom or Oricom's authorised service provider.

Oricom will not be liable for any damages caused by the product or the failure of the product to perform, including any lost profits or savings or special, incidental or consequential damages. Oricom is not liable for any claim made by a third party or made by you on behalf of a third party. This limitation of liability applies whether damages are sought, or a claim made, under this Warranty or as a tort claim (including negligence and strict product liability), a contract claim or any other claim. However, this limitation of liability will not apply to claims for personal injury. Nothing in this Warranty excludes, restricts or modifies any condition, warranty, right or remedy which pursuant to the Competition and Consumer Act 2010 applies to this Warranty and which may not be so excluded, restricted or modified. For warranties that cannot be excluded, restricted or modified, Oricom limits the remedies available to those specified in the relevant legislation. Oricom products come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

**Contact details for Oricom support and warranty claims in Australia**

Oricom International Pty Ltd  
Locked Bag 658  
South Windsor, NSW 2756  
Australia

Email: [support@oricom.com.au](mailto:support@oricom.com.au)  
Phone: 1300 889 785  
(Monday to Friday 8am to 6pm AEST)  
Web: [www.oricom.com.au](http://www.oricom.com.au)  
Fax: (02) 4574 8898

**Contact details for Oricom support and warranty claims in  
New Zealand**

Email: [support@oricom.co.nz](mailto:support@oricom.co.nz)  
Phone: 0800 674 266  
(Monday to Friday 10am to 8pm NZST)  
Web: [www.oricom.co.nz](http://www.oricom.co.nz)



Ref: 19032012