



Oricom AD50 Aroma Diffuser Night Light

User Guide



Oricom AD50 Aroma Diffuser Night Light


This Aroma Diffuser uses Ultrasonic waves to continually vaporize water and essential oil in the water tank, to produce a cool, fragrant mist.

Specifications

Size	120mm (dia)*160mm (height)
Weight	400g
Power adaptor	AC100-240V 50/60Hz 24V
Length of cord	About 1.5m
Power consumption	7~14W
Interval time	Spray for 10s / pause for 10s
Water capacity	160ml
LED light	4PCS RGB LED
Original material	ABS+PP
Ultrasonic frequency	2.4MHZ

Operation

1. Connect the AC adaptor to the DC jack at the base of the main body via cable guide.
2. Remove upper cover. (Fig 2)
3. Add water into the water tank; do not exceed the max line on the water tank. (Fig 3)
4. Drop essential oil into the water tank vertically, the dosage is about 2-3 drops (about 0.1-0.15ML) per 100ML water. (Fig 3)
5. Install the cover of the main body and twist into position. (Fig 4)
IMPORTANT: The upper cover must be in position before using the product.
6. Connect power adaptor to a wall plug.



Oricom AD50 Aroma Diffuser Night Light

7. Press the "MIST" button:

1st press: 1 short click to activate the diffuser for spraying. The unit will automatically shut off when it detects a low water level in the reservoir.

2nd press: "2 clicks" to enter the interval mode for cycling through spray for 10s, pause for 10s.

3rd press: the diffuser will shut off.

8. Press the "LIGHT" button to cycle through the different colour selections. Hold the "LIGHT" button for two seconds to turn the light off.

9. The diffuser will automatically shut off when it detects a low water level in the reservoir. The diffuser can also be manually shut off by holding the "MIST" button for two seconds.

Attention

- The amount and intensity of mist produced will vary, but this is not unusual and should not be considered a fault. Factors that affect this include water level in the water tank, water type, humidity, temperature, air currents and so on.
- The unit will not work without water.
- Use 2-3 drops essential oil per 100ML water *only*. Too much oil will clog the system and cause malfunction. Please clean the unit as per the maintenance instructions, before changing to a new type of essential oil.
- Add water first, followed by the essential oil, as the essential oil may block the Ultrasonic vibration plate and cause malfunction.

Accidental leakage

In the event the unit is knocked over or spillage occurs during use, please follow the steps below to avoid malfunction.

- Unplug the unit and remove cover.
- Empty water tank.
- Shake the unit gently to drain any water inside the mechanism, and then allow to dry for at least 24 hours.

Maintenance

After 5-6 uses or 3-5 days of operation, please clean the product as follows:

- Unplug the unit from mains supply and remove cover.
- Unplug power cord from base of unit.
- Add 1 tablespoon of citric acid in the water tank, add just under 100ml of warm water (up to 70°C).
- Wipe with a soft cloth. Avoid Ultrasonic Vibration plate area, which can be gently cleaned with a cotton bud.

Precautions

- Add water into the water tank first, then drop essential oil into water tank.
- Do not fill over 160ML "MAX" at any time.
- Do not switch on power when the tank is empty.
- Do not touch the Ultrasonic vibration plate.
- Clean regularly as per maintenance instructions to avoid malfunction.
- Always unplug from power supply before maintenance.
- After use, empty remaining water and wipe with a clean dry cloth.
- Essential oil can stain the Ultrasonic vibration plate, please wipe away with a soft cloth and clean water.
- Do not let mist blow directly onto furniture, clothing, walls etc.
- Keep away from electronic equipment, such as TV and Audio equipment.
- Do not tip the product. This may cause water to enter the mechanism and cause malfunction.
- Do not use for more than 10 hours continuously.
Wait 60 minutes before restart to avoid damage to Ultrasonic vibration plate.
- Use tap water only. Do not use mineral water, sparkling water etc.
- Do not move product while in use.
- Do not touch any part of the product with wet hands.
- Keep out of reach of children and pets. Also, this appliance is not to be used by children or persons with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction.
- Keep cord clear of pathways, and do not pull forcefully at any point.
- If smoke or burning smell is detected, unplug immediately.

Express Warranty (Australia)

This Express Warranty is provided by Oricom International Pty Ltd ABN 46 086 116 369, Unit 1, 4 Sovereign Place, South Windsor NSW 2756, herein after referred to as "Oricom".

Oricom products come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

Oricom warrants that the product is free from defects in materials or workmanship during the Express Warranty Period. This Express Warranty does not extend to any product from which the serial number has been removed or was purchased outside of Australia.

Nothing in this Express Warranty excludes, restricts or modifies any condition, warranty, guarantee, implied term, right or remedy pursuant to the Australian Consumer Law and which may not be so excluded, restricted or modified. For such conditions, terms, guarantees and warranties that cannot be excluded, restricted or modified, Oricom limits the remedies available to extent permitted in the relevant legislation.

Except with respect to rechargeable battery cells and rechargeable battery packs (if supplied), the Express Warranty Period will be 12 months from the date of purchase of the product evidenced by your dated sales receipt. You are required to provide proof of purchase as a condition of receiving Express Warranty services. Rechargeable battery cells and rechargeable battery packs (if supplied) with this product are covered under this warranty for a period of 6 months.

You are entitled to a replacement product or repair of the product at our discretion according to the terms and conditions of this document if your product is found to be faulty within the Express Warranty Period. This Express Warranty extends to the original purchaser only and is not transferable.

Products distributed by Oricom are manufactured using new materials or new and used materials equivalent to new in performance and reliability. Spare parts may be new or equivalent to new. Spare parts are warranted to be free from defects in material or workmanship for thirty (30) days or for the remainder of the Express Warranty Period of the Oricom branded product in which they are installed, whichever is longer. During the Express Warranty Period, Oricom will where possible repair and if not replace the faulty product or part thereof. All component parts removed under this Express Warranty become the property of Oricom. In the unlikely event that your Oricom product has a recurring failure, Oricom may always, subject to the Competition and Consumer Act 2010, at its discretion, elect to provide you with a replacement product of its choosing that is at least equivalent to your product in performance.

No change to the conditions of this Express Warranty is valid unless it is made in writing and signed by an authorised representative of Oricom.

Oricom will not be liable under this Express Warranty, and to the extent permitted by law, will not be liable for any defect, loss, damage or injury arising out of or in connection with a:

10. failure by you to adhere to the warnings and follow the instructions set out in this user guide for the proper installation and use of the product;
11. willful misconduct or deliberate misuse by you of the product;
12. any external cause beyond our control, including but not limited to power failure, lightning or over voltage; or
13. modification to the product or services carried out on the product by anyone other than Oricom or Oricom's authorised service provider.

How to make a claim under your Express Warranty in Australia

Oricom has a simple warranty process for you to follow:

- Please call our Customer Support Team on 1300 889 785, or email support@oricom.com.au.
- A Customer Support Team member will verify, after troubleshooting with you, if your product qualifies under warranty. If so, they will give you a Product Return Authorisation number.
- We will then email or fax a Return Authorisation form and a Repair Notice (if necessary), together with instructions on how to return the goods for warranty service.

Please note that if a Customer Support Team member advises that your product does not qualify for return, this warranty does not apply to your product. Products that are authorised to be returned to Oricom in Australia must include all of the following:

- A completed Return Authorisation form
- A copy of your Proof of Purchase (please keep your original copy)
- The faulty product, including all accessories.

Send the approved returns to:

Oricom International Pty Ltd
Locked Bag 658
South Windsor NSW 2756 Australia

Please note that this Express Warranty excludes expenses incurred by you in returning any faulty product to us. You must arrange and pay any expenses incurred (including postage, delivery, freight, transportation or insurance of the product) to return the faulty product to us, however, we will arrange delivery of the repaired or replaced faulty product to you.

Important Information - Repair Notice

Please be aware that the repair of your goods may result in the loss of any user-generated data (such as stored telephone numbers, text messages and contact information). Please ensure that you have made a copy of any data saved on your goods before sending for repair. Please also be aware that goods presented for repair may be replaced by refurbished goods or parts of the same type rather than being repaired.

ORICOM CUSTOMER SUPPORT

Oricom have a trained and dedicated team of Customer Support Representatives, each with the knowledge and resources to assist in answering your questions quickly and efficiently.

Oricom Support - Australia

For all product enquiries, troubleshooting or to discuss the range of Oricom products, feel free to contact Oricom or visit our website for answers to frequently asked questions.

1300 889 785

Monday - Friday 8am – 6pm AEST

Email: support@oricom.com.au

www.oricom.com.au

Oricom Support - New Zealand**0800 674 266**

Monday - Friday 10am - 8pm NZST

Email: support@oricom.co.nz

www.oricom.co.nz

