




Wake'n' Shake Curve



INSTRUCTION MANUAL

KEEP THIS USER GUIDE FOR FUTURE REFERENCE
Always retain your proof of purchase in case of warranty service.
AUSTRALIA: www.oricom.com.au NEW ZEALAND: www.oricom.co.nz



TO SET TIME AND THE SNOOZE DURATION

1. Press **SET** once, the hour digits "0" flash. Press ▲ or ▼ to set the time in hours (hold to advance rapidly).
2. Press **SET** again, the minute digits "00" flash. Press ▲ or ▼ to set the time in minutes. (hold to advance rapidly).
3. Press **SET** again, the display shows "24Hr" and flashes. Press ▲ or ▼ to select "12Hr" or "24Hr" time format. The **PM** LED will appear on the lower right to indicate the afternoon time; there is no **AM** indicator.
4. Press **SET** again, the display shows "05" and flashes. Press ▲ or ▼ to select your snooze time from 5 to 60 minutes.
5. Press **SET** again or if no key pressed for approx. 10 seconds to exit the setting mode.

TO SET THE ALARM

1. Press and hold **AL SET / SELECT**, the  LED and the hour digits flash. Press ▲ or ▼ to set the alarm in hours. (Hold to advance rapidly).
2. Press **AL SET / SELECT** once again, the minute digits flash. Press ▲ or ▼ to set the alarm in minutes. (Hold to advance rapidly).
3. Press **AL SET / SELECT** again, LED displays "HI" (vibration at HI level), press ▲ or ▼ to select "LO" (vibration at Lo level)
4. Press **AL SET / SELECT** once again, LED displays "F-1 (ex. 800 Hz)" and flash, press ▲ or ▼ to select the alarm tone (frequency) :
F-1 (low tone, 800 Hz), F-2 (mid tone, 1 KHz), F-3 (high tone, 1.5 KHz)
5. Press **AL SET / SELECT** once again or no button around 10 seconds to exit the alarm setting mode.

TO TURN ON/OFF AND SELECT THE ALARM MODE

1. At normal time display mode, press **AL SET / SELECT** one at a time to activate the alarm(s) and turn on corresponding alarm indicator(s) on the left side of the time display:

-  : only shaker activated
-  : both sound and shaker alarm activated
-  : both strobe light and shaker alarm activated
-  : both strobe light, sound and shaker alarm activated

2. Press **AL SET / SELECT** once more to turn off all the alarms, all  and  alarm indicators are turned off.

Note: To use the shaker alarm, please plug in the shaker plug to the back of the clock. If user doesn't want to use the shaker alarm, unplug the shaker plug from the clock.

TO ADJUST YOUR ALARM VOLUME (BUZZER)

You can turn the volume dial at the right side of your clock to adjust the alarm volume.

This alarm clock can be set to loud volume levels – please use with care. Increase volume gradually to a comfortable level.

TO STOP AND RESET THE ALARM TO COME ON THE NEXT DAY

When alarm is sounding, the corresponding alarm indicator flashes. Press **AL SET / SELECT** once to stop the alarm and reset it to come on the following day. After that, the corresponding alarm indicator stays on the display.

TO USE SNOOZE (default snooze duration is 5 minutes)

When alarm is sounding, press **Zz**  once, the alarm will stop temporarily and the corresponding alarm indicator will keep flashing. The alarm will come on again after the set snooze duration is over.

TO USE THE HI-MED-LO DIMMER (LED TIME DIGITS)

There is a 3-level brightness control for the LED clock display. Press **Zz**  to adjust the brightness (**HI / MED / LO**) of the LED display. This can only be done when the unit is not alarming. At the start, the brightness is setting on Hi position.

CHARGE YOUR MOBILE PHONE WITH USB PORT

Connect the charging cable of your mobile phone to the USB port at the back of the clock and then connect the other end to the micro USB charging socket on your mobile phone. The clock will charge the mobile phone automatically.

- Note :
1. Make sure the cable supplied with your mobile phone is used for charging.
 2. Make sure the adaptor supplied with this clock (9V 1.5A) is used to power it.
 3. It is not possible to charge an iPad® or notepad from the USB socket on this clock.

CARE OF YOUR PRODUCT

1. Place your clock on a stable surface, away from sources of direct sunlight or excessive heat or moisture.

2. Protect your furniture when placing your unit on a natural wood and lacquered finish by using a cloth or protective material between the unit and the furniture.
3. Clean your unit with a soft cloth moistened only with mild soap and water. Stronger agents such as benzene, thinners or similar materials can damage the surface of the unit. Make sure the unit is unplugged before cleaning.
4. Remove the back-up battery if the clock is not going to be used for a month or longer to prevent possible corrosion. Should the battery compartment become corroded or dirty, clean the compartment thoroughly and replace the battery.

SPECIFICATIONS

Alarm duration	: 1 hour
Snooze duration Adjustable	: 5 to 60 minutes
Default settings	Time format : 24 hour
	Time : 0:00
	Alarm : 6:00
	Alarm and shaker level : HI
	Alarm sound frequency : F-1
	Snooze duration : 05 (5 minutes)
Audible alarm	: 95 dB at 1m

Express Warranty (Australia)

This Express Warranty is provided by Oricom International Pty Ltd ABN 46 086 116 369, Unit 1, 4 Sovereign Place, South Windsor NSW 2756, herein after referred to as "Oricom".

Oricom products come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

Oricom warrants that the product is free from defects in materials or workmanship during the Express Warranty Period. This Express Warranty does not extend to any product from which the serial number has been removed or was purchased outside of Australia.

Nothing in this Express Warranty excludes, restricts or modifies any condition, warranty, guarantee, implied term, right or remedy pursuant to the Australian Consumer Law and which may not be so excluded, restricted or modified. For such conditions, terms, guarantees and warranties that cannot be excluded, restricted or modified, Oricom limits the remedies available to extent permitted in the relevant legislation.

The Express Warranty Period will be 12 months from the date of purchase of the product evidenced by your dated sales receipt. You are required to provide proof of purchase as a condition of receiving Express Warranty services.

You are entitled to a replacement product or repair of the product at our discretion according to the terms and conditions of this document if your product is found to be faulty within the Express Warranty Period. This Express Warranty extends to the original purchaser only and is not transferable.

Products distributed by Oricom are manufactured using new materials or new and used materials equivalent to new in performance and reliability. Spare parts may be new or equivalent to new. Spare parts are warranted to be free from defects in material or workmanship for thirty (30) days or for the remainder of the Express Warranty Period of the Oricom branded product in which they are installed, whichever is longer. During the Express Warranty Period, Oricom will where possible repair and if not replace the faulty product or part thereof. All component parts removed under this Express Warranty become the property of Oricom. In the unlikely event that your Oricom product has a recurring failure, Oricom may always, subject to the Competition and Consumer Act 2010, at its discretion, elect to provide you with a replacement product of its choosing that is at least equivalent to your product in performance.

No change to the conditions of this Express Warranty is valid unless it is made in writing and signed by an authorised representative of Oricom.

Oricom will not be liable under this Express Warranty, and to the extent permitted by law will not be liable for any defect, loss, damage or injury arising out of or in connection with a:

1. Failure by you to adhere to the warnings and follow the instructions set out in this user guide for the proper installation and use of the product;
2. Wilful misconduct or deliberate misuse by you of the product;
3. Any external cause beyond our control, including but not limited to power failure, lightning or over voltage; or
4. Modification to the product or services carried out on the product by anyone other than Oricom or Oricom's authorised service provider.

How to make a claim under your Express Warranty in Australia

Oricom has a simple warranty process for you to follow:

- Please call or email our Customer Support Team, 1300 889 785 or support@oricom.com.au.
- A Customer Support Team member will verify after troubleshooting with you if your product qualifies under warranty. If so, they will give you a Product Return Authorisation number.
- We will then email or fax a Return Authorisation form and a Repair Notice (if necessary), together with instructions on how to return the goods for warranty service.

Please note that if a Customer Support Team member advises that your product does not qualify for return, this warranty does not apply to your product. Products that are authorised to be returned to Oricom in Australia must include all of the following:

- A completed Return Authorisation form
- A copy of your Proof of Purchase (please keep your original copy)
- The faulty product, including all accessories.

Send the approved returns to:

Oricom International Pty Ltd
Locked Bag 658
South Windsor NSW 2756 Australia

Please note that this Express Warranty excludes expenses incurred by you in returning any faulty product to us. You must arrange and pay any expenses incurred (including postage, delivery, freight, transportation or insurance of the product) to return the faulty product to us, however, we will arrange delivery of the repaired or replaced faulty product to you.

Important Information

Repair Notice

Please be aware that the repair of your goods may result in the loss of any user-generated data (such as stored telephone numbers, text messages and contact information). Please ensure that you have made a copy of any data saved on your goods before sending for repair. Please also be aware that goods presented for repair may be replaced by refurbished goods or parts of the same type rather than being repaired.

ORICOM CUSTOMER SUPPORT

Oricom have a trained and dedicated team of Customer Support Representatives, each with the knowledge and resources to assist in answering your questions quickly and efficiently.

Oricom Support - Australia

For all product enquiries, troubleshooting or to discuss the range of Oricom products, feel free to contact Oricom or visit our website for answers to frequently asked questions.

1300 889 785

Monday - Friday 8am – 6pm AEST
Email: support@oricom.com.au
www.oricom.com.au

Oricom Support - New Zealand

0800 674 266

Monday - Friday 10am - 8pm NZST
Email: support@oricom.co.nz
www.oricom.co.nz

BACKUP BATTERY INSTALLATION

Your clock requires one CR2032 lithium battery (not included) to provide backup power to the clock in the event of a temporary power interruption.

1. Place your unit face down on a flat and soft surface.
2. Use screw driver to open the backup battery compartment door located on the back of the unit.
3. Slide and remove the battery cover at the bottom of your unit.
4. Insert one new CR2032 lithium battery into the battery compartment with the "+" side facing up as indicated.
5. Close the battery compartment door and tighten the battery door screw.

If mains power is interrupted or the adaptor is unplugged, the LED clock display will go off and the alarm will not function.

Please replace the battery every year to ensure that your device is not damaged.

INSTALLATION

Plug the AC/DC adaptor to an AC household outlet, and then plug the DC jack to the back of the unit. Your clock is ready to work for you.