



# Baby Monitor Secure715



**User Guide**

**KEEP THIS USER GUIDE FOR FUTURE REFERENCE**

Always retain your proof of purchase in case of warranty service.  
AUSTRALIA: [www.oricom.com.au](http://www.oricom.com.au) NEW ZEALAND: [www.oricom.co.nz](http://www.oricom.co.nz)

# TABLE OF CONTENTS

|  |    |
|--|----|
| SAFETY INFORMATION                         | 1  |
| OVERVIEW OF FUNCTIONAL COMPONENT POSITIONS | 3  |
| GETTING STARTED                            | 5  |
| USING THE BABY MONITOR                     | 7  |
| TROUBLESHOOTING                            | 12 |
| EXPRESS WARRANTY                           | 13 |

## Need Help?

If you need assistance setting up or using your Oricom product now or in the future, call Oricom Support.

Australia            1300 889 785 or 02 4574 8888  
                              [www.oricom.com.au](http://www.oricom.com.au)  
                              Mon-Fri 8am – 6pm AEST

New Zealand        0800 67 42 66  
                              [www.oricom.co.nz](http://www.oricom.co.nz)  
                              Mon-Fri 10am – 8pm NZST

## 1 Important Safety Information

---

- It is very important that you read the User Guide carefully as it contains detailed information you will need to get the most from your Oricom baby monitor. If you have any issues setting up or using your Oricom baby monitor, please call our Customer Support team.
- Your Oricom baby monitor is designed to be an aid and should not be used as a substitute for responsible and proper adult supervision of a child.
- The baby monitor has been designed to provide some added reassurance in the form of sound transmission for those times when you are not in the same room as your baby provided you always stay within hearing range of the baby monitor during use. Your baby monitor is not a medical device, nor a device to prevent cases of Sudden Infant Death Syndrome (SIDS) or "cot death", and you should not rely on it for your baby's wellbeing. It is important that you regularly check on your baby personally.
- Make sure the baby unit, parent unit and mains adaptor cables are kept out of reach of your baby and other young children at all times, at least one metre away.
- Never place the baby unit or parent unit inside your baby's cot, bed or playpen.
- Never cover the parent or baby units with clothes, towels or blankets or any other item. Never use or place your parent or baby unit in or near moisture or water (e.g. near bath or pool). Immersing in water could cause electric shock and even death.
- The installation location plays an important role in ensuring proper operation. Therefore, maintain a distance of at least one metre from other electronic equipment, such as microwave ovens or hi-fi devices, otherwise they could cause interference. During continual use the baby unit power adaptors may become warm to the touch. This is normal and should not be a concern.



### Warning

Risk of suffocation!

Keep all packaging materials and protective foils out of reach of children.

## 2 SAFETY INFORMATION



### Warning

Do not place the AC Adaptor cable in a high "wear and tear" location. Never use a frayed or compromised cord.

### Battery safety

- Batteries represent a hazard to health and the environment!
- They contain toxic, ecologically hazardous heavy metals. Do not dispose of batteries in a fire as they may explode. Dispose of batteries according to local regulations, never in your household rubbish.
- Do not dismantle, cut, open, crush, bend, puncture, or shred cells or batteries. If a battery leaks, do not let the battery liquid touch skin or eyes. If this happens, immediately flush the affected areas with water, and seek medical assistance.
- Do not modify, remanufacture, attempt to insert foreign objects into the battery, or immerse or expose it to water or other liquids. Batteries may explode if damaged.
- Use only the batteries supplied with the product. Improper use, or use of unapproved batteries, may present a risk of fire, explosion, or other hazard, and may invalidate any approval or warranty.
- If you believe the battery is damaged, remove product from the charger and stop using the product. Contact Oricom for assistance. Never use a damaged battery.

### Disposal


Always dispose of your products at the end of their life in accordance with your local waste disposal requirements.

**Packaging materials** all cardboard and paper packaging should be recycled in accordance with your local council waste regulations.

## 2 Your Baby Monitor

---


### Parent Unit



- 1 Power
- 2 Power / OK Button
- 3 Up Button
- 4 PTT / Lullaby Button
- 5 Menu Button
- 6 Down Button

# 4 OVERVIEW OF FUNCTIONAL COMPONENT POSITIONS

## Camera unit (Baby Unit)



- 1 Baby Unit Power Indicator
- 2 Pairing Button

## Check pack contents

|                                  |
|----------------------------------|
| SC715                            |
| 1 Baby unit (camera)             |
| 1 AC adaptor for the baby unit   |
| 1 Parent unit                    |
| 2 x AA 800mAh NiMH batteries     |
| 1 AC adaptor for the parent unit |

If any items are missing, contact Oricom customer support on 1300 889 785 or [support@oricom.com.au](mailto:support@oricom.com.au).

## 3 Getting Started

---

### NOTE:

YOU MUST INITIALLY CHARGE THE BATTERIES FOR 12-14 HOURS BEFORE USE. THIS IS IMPORTANT TO MAINTAIN ADEQUATE BATTERY PERFORMANCE.

### 3.1 Baby unit power supply

- (1) Connect the power adaptor with microUSB to the baby unit.



#### Warning

Only use the AC power adaptor supplied with the product as other power adaptors could damage the product. This product is designed for indoor use only.

### 3.2 Turn on/off the Parent unit

- (1) Insert batteries into the battery compartment.
- (2) Close the battery compartment.
- (3) Press and hold <POWER> button for 2 seconds to switch on the parent unit. It will take a few seconds to start up the unit. The LCD will display Oricom loading screen.
- (4) Press and hold <POWER> key for 2 seconds again to turn OFF the parent unit.

### NOTE:

When the battery level is low, the LCD will show the battery empty icon, which will flash.

### 3.3 Charge the Battery on the Parent unit

- (1) Connect the Micro USB power adaptor to the parent unit and other end to the mains power.
- (2) Battery icon with lightning symbol is shown on the LCD.

### Battery Life

The rechargeable batteries (supplied) can be charged and discharged hundreds of times, however they will eventually wear out and lose their ability to hold a full charge. When the in-use time becomes noticeably shorter than normal, it is time to purchase new batteries.

### How to purchase spare parts

You can purchase batteries (Part number: 2B0109), and extra camera units from Oricom [www.oricom.com.au](http://www.oricom.com.au)



#### Warning

Only use Rechargeable Nickel Metal Hydride batteries in this product, as any other type may cause damage.

---

# 6 GETTING STARTED

## 4 Using The Baby Monitor

---

Once the baby and parent units are powered on and registered, the display on the parent unit will show the video captured by the baby unit.

### Switching on the Parent Unit

Press and hold the <POWER> button for approx. 2 seconds, until the Oricom logo appears on the parent unit. The camera image will then appear.

Press and hold the <POWER> button for approx. 2 seconds to switch the unit off.

### NOTE:

If you place the parent and baby units too close together, you will hear a high pitched noise called "feedback" this is normal. The units are designed to be located in separate rooms.

To prevent feedback, avoid having the parent unit and baby unit turned on in the same room.

Feedback will be generated if the talk button is pressed when the baby unit and parent unit are too close to each other.

### 4.1 Video mode

The baby and parent units are pre-registered. Once the baby and parent units are switched on the parent unit will show the video captured by the baby unit.

#### 4.1.1 Sound level adjustment

During video mode, you can press the <DOWN> key to enable sound level adjustment, you can now adjust the volume by pressing the <UP>/<DOWN> keys.

Press the menu key to save and exit.

#### 4.1.2 Brightness adjustment

During video mode, you can press the <UP> key to enable brightness adjustment, you can now adjust the brightness by pressing the <UP>/<DOWN> keys.

Press the menu key to save and exit.

#### 4.1.3 Lullaby selection

During video mode, press the <PTT/LULLABY> key to enable/disable lullabies. You can then press the <UP/DOWN> keys within 8 seconds to choose from lullabies 1 to 5 or cycle.


#### 4.1.4 Push to talk

During video mode, press and hold <PTT/LULLABY> key to enable the push to talk function. The following graphic will be shown. Voice will be transmitted from parent unit to the baby unit.




**NOTE:**

Lullabies will continue to play on the baby unit when the parent unit is turned OFF. To turn off the lullabies on the baby unit: turn the parent unit back ON, then turn the lullabies off in the menu.

**4.2 MENU mode**

(1) Press the <MENU> button in Video mode to enter the MENU. In the menu you have the following options:

CAMERA SELECTION / VOX SELECTION / ZOOM / SETUP

**NOTE:**

Different options can be selected via the <UP>/<DOWN> buttons, press <OK> button to confirm. Press the <MENU> button any time to exit the MENU.

**4.2.1 CAMERA SELECTION**

- (1) You can select your viewing camera in the camera selection menu via the <UP>/<DOWN> keys.
- (2) If more than one camera is registered, you can select camera scan function, video from each camera will then display for 10 seconds.

**4.2.2 VOX SELECTION**

You can select VOX on/off. During VOX on, parent unit display will turn off once the voice level in the baby unit is below the threshold. You can activate the video and audio at anytime by pressing the <POWER> keys.

Note : To conserve power,VOX is on automatically when parent unit is operated by battery.

(1) VOX sensitivity level

Once VOX on is enabled, VOX sensitivity level and VOX timer can be selected.

You can select the VOX sensitivity level (5 Levels) by pressing the <UP>/<DOWN> keys, press <OK> to save.

# 8 USING THE BABY MONITOR

## (2) VOX timer


After setting the VOX sensitivity level, you can then select the VOX timer. VOX timer duration can be selected with the <UP>/<DOWN> keys from 10, 30 or 90 seconds. This setting determines the duration the screen is on when VOX has been activated.

## 4.2.3 ZOOM

You can select x1 or x2 ZOOM on the video display. Selecting x2 Zoom will magnify the display.

## 4.2.4 SETUP mode

In setup mode, you have the following options: CAMERA REGISTRATION / DE-REGISTRATION/ LULLABY and VOLUME SETTINGS. Use the <UP>/<DOWN> keys for selection, confirm and exit with the <OK> key. Press the <MENU> key anytime to exit.




## 4.2.4.1 Camera registration / de-registration

In the camera registration / de-registration option in the settings menu, the camera registration status is shown. Tick mark indicates the camera is registered. Cross mark indicates the camera is not registered.



- (1) You can select the camera to register / de-register by pressing the <UP>/<DOWN> keys and confirming the selection by pressing <OK>.
- (2) Once the camera is selected for registration, the following screen will be shown. Press the <PAIRING> key on the back of the baby unit in order to register the new camera.




## 4.2.4.2 Lullaby volume setting

In the lullaby volume setting, you can set the lullaby volume level via the <UP>/<DOWN> keys and confirm by pressing the <OK> key.

## 4.3 Lost link indication

When the baby unit is not powered on or is out of range, the following graphic will be shown on the LCD display and the POWER LED in parent unit will flash.



## 4.4 Cleaning

Wipe down the monitor with a clean dry cloth. DO NOT use any chemical cleaner or solvents on your baby monitor.

# 10 USING THE BABY MONITOR

## 5 Customer Support

Should you experience difficulties operating the SC715, please refer to the troubleshooting guide below. If you still experience difficulties, please contact Oricom Customer Support on 1300 889 785 for assistance.

### Troubleshooting

| Problems                                       | Solutions  |
|--|--|
| Equipment does not function                    | <ul style="list-style-type: none"><li>– Check both parent unit and baby unit are turned on</li><li>– Check parent unit is charged or placed on charge.</li><li>– Check baby unit is connected to power.</li></ul>  |
| Lost link displaying on parent unit            | <ul style="list-style-type: none"><li>– Move the parent unit closer to the baby unit.</li><li>– Try resetting your monitor to avoid busy channels:<ol style="list-style-type: none"><li>1. Turn both camera and parent units off and remove the battery in the parent unit. Leave unplugged for 1 minute.</li><li>2. If you have Wi-Fi in the home, make it busy by streaming a video on YouTube or similar.</li><li>3. Turn the camera back on wait for 30 seconds.</li><li>4. Plug the battery into the parent unit and turn on.</li></ol></li></ul> |
| Reception interference                         | <ul style="list-style-type: none"><li>– Move the parent unit closer to the baby unit.</li><li>– Reposition the baby unit slightly.</li><li>– Check for interference from other electronic devices such as Wi-Fi.</li></ul>   |
| High pitched noise from parent unit - Feedback | <ul style="list-style-type: none"><li>– Increase the distance between the parent unit and baby unit.</li><li>– Reduce the volume on the parent unit.</li></ul>   |
| Amber power LED flashing                       | <ul style="list-style-type: none"><li>– The battery level is low. Return the parent unit to the charger.</li></ul>   |
| Picture but no sound                           | <ul style="list-style-type: none"><li>– Increase the volume on the parent unit.</li></ul>  |
| Picture is in black and white                  | <ul style="list-style-type: none"><li>– Night function is active. Increase the light level in the baby's room if required.</li></ul>   |

# USING THE BABY MONITOR 11

|   |   |
|---|---|
| Picture on parent unit not displaying correctly | – Switch off parent unit then camera unit. Wait 10 seconds. Switch on the camera unit then parent unit (in that order)  |
| Battery not charging                            | – Check batteries and battery connections are clean and free of corrosion.<br>– After a period of time, the batteries may need to be replaced due to everyday usage. Please visit <a href="http://www.oricom.com.au">www.oricom.com.au</a> to purchase replacement batteries. |
| Parent unit beeping                             | Move the parent unit closer to the baby unit until they are within range.   |
| No picture after 10 seconds                     | VOX function is activated. Turn off VOX if required. During battery operation, VOX cannot be turned off.  |
| Picture changes every 10 seconds                | Scan function is on. Turn off the scan function.  |

## 6 Technical Specifications

### Technical data

| Feature                      | Value  |
|------------------------------|--|
| Camera<br>(baby unit)        | Micro USB: 5 V DC<br>Sensor: 1 night light sensor<br>IR diodes: 4pcs                                 |
| Monitor<br>(parent unit)     | Screen: 2.4" LCD display<br>Micro USB: 5 V DC  |
| Battery Pack for Parent unit | Rechargeable 2 x AA 800mAh NiMH batteries  |
| Power supply (parent unit)   | AC Power adaptor, input: 100-240 V AC, 50-60 Hz, 150 mA<br>Power adaptor plug, output: 5 V DC, 1.0 A |
| Battery performance          | Up to 8 hours of continuous operation when new battery is fully charged, with VOX turned on.         |

# 12 TROUBLESHOOTING

|                                 |   |
|---------------------------------|---|
| Power supply (baby unit)        | AC Power adaptor, input: 100-240 V AC, 50-60 Hz, 150 mA<br>Power adaptor plug, output: 5 V DC, 1.0 A  |
| Range                           | Up to 150 meters under optimum conditions.<br>Range is reduced in buildings through walls, doors etc. |
| Frequency range                 | 2.4 GHz Digital FHSS  |
| Permissible ambient temperature | 0°C to 40°C   |

## NOTE

For a replacement battery pack or other spare parts, please contact Oricom.

## Express Warranty (Australia)

This Express Warranty is provided by Oricom International Pty Ltd ABN 46 086 116 369, Unit 1, 4 Sovereign Place, South Windsor NSW 2756, herein after referred to as "Oricom".

Oricom products come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

Oricom warrants that the product is free from defects in materials or workmanship during the Express Warranty Period. This Express Warranty does not extend to any product from which the serial number has been removed or was purchased outside of Australia.

Nothing in this Express Warranty excludes, restricts or modifies any condition, warranty, guarantee, implied term, right or remedy pursuant to the Australian Consumer Law and which may not be so excluded, restricted or modified. For such conditions, terms, guarantees and warranties that cannot be excluded, restricted or modified, Oricom limits the remedies available to extent permitted in the relevant legislation.

The Express Warranty Period will be 3 years from the date of purchase of the product evidenced by your dated sales

receipt. You are required to provide proof of purchase as a condition of receiving Express Warranty services.

You are entitled to a replacement product or repair of the product at our discretion according to the terms and conditions of this document if your product is found to be faulty within the Express Warranty Period. This Express Warranty extends to the original purchaser only and is not transferable.

Products distributed by Oricom are manufactured using new materials or new and used materials equivalent to new in performance and reliability. Spare parts may be new or equivalent to new. Spare parts are warranted to be free from defects in material or workmanship for thirty (30) days or for the remainder of the Express Warranty Period of the Oricom branded product in which they are installed, whichever is longer. During the Express Warranty Period, Oricom will where possible repair and if not replace the faulty product or part thereof. All component parts removed under this Express Warranty become the property of Oricom. In the unlikely event that your Oricom product has a recurring failure, Oricom may always, subject to the Competition and Consumer Act 2010, at its discretion, elect to provide you with a replacement product of its choosing that is at least equivalent to your product in performance.

No change to the conditions of this Express Warranty is valid unless it is made in writing and signed by an authorised representative of Oricom.

# 14 EXPRESS WARRANTY

Oricom will not be liable under this Express Warranty, and to the extent permitted by law will not be liable for any defect, loss, damage or injury arising out of or in connection with a:

1. failure by you to adhere to the warnings and follow the instructions set out in this user guide for the proper installation and use of the product;
2. wilful misconduct or deliberate misuse by you of the product;
3. any external cause beyond our control, including but not limited to power failure, lightning or over voltage; or
4. modification to the product or services carried out on the product by anyone other than Oricom or Oricom's authorised service provider.

## How to make a claim under your Express Warranty in Australia

Oricom has a simple warranty process for you to follow:

- Please call or email our Customer Support Team, 1300 889 785 or support@oricom.com.au.
- A Customer Support Team member will verify after troubleshooting with you if your product qualifies under warranty. If so, they will give you a Product Return Authorisation number.
- We will then email or fax a Return Authorisation form and a Repair Notice (if necessary), together with instructions on how to return the goods for warranty service.

Please note that if a Customer Support Team member advises that your product does not qualify for return, this warranty does not apply to your product. Products that are authorised to be returned to Oricom in Australia must include all of the following:

- A completed Return Authorisation form
- A copy of your Proof of Purchase (please keep your original copy)
- The faulty product, including all accessories.



Send the approved returns to:

Oricom International Pty Ltd

Locked Bag 658

South Windsor NSW 2756 Australia

Please note that this Express Warranty excludes expenses incurred by you in returning any faulty product to us. You must arrange and pay any expenses incurred (including postage, delivery, freight, transportation or insurance of the product) to return the faulty product to us, however, we will arrange delivery of the repaired or replaced faulty product to you.

## **Important Information**

### **Repair Notice**

Please be aware that the repair of your goods may result in the loss of any user-generated data (such as stored telephone numbers, text messages and contact information). Please ensure that you have made a copy of any data saved on your goods before sending for repair. Please also be aware that goods presented for repair may be replaced by refurbished goods or parts of the same type rather than being repaired.

## ORICOM CUSTOMER SUPPORT

Oricom have a trained and dedicated team of Customer Support Representatives, each with the knowledge and resources to assist in answering your questions quickly and efficiently.

### **Oricom Support - Australia**

For all product enquiries, troubleshooting or to discuss the range of Oricom products, feel free to contact Oricom or visit our website for answers to frequently asked questions.

**1300 889 785**

Monday - Friday 8am – 6pm AEST

Email: [support@oricom.com.au](mailto:support@oricom.com.au)

[www.oricom.com.au](http://www.oricom.com.au)

### **Oricom Support - New Zealand**

**0800 674 266**

Monday - Friday 10am - 8pm NZST

Email: [support@oricom.co.nz](mailto:support@oricom.co.nz)

[www.oricom.co.nz](http://www.oricom.co.nz)

