

## 封面

## 封底

## 正面



### User Guide

Oricom OLS50 Portable Sound Soother with Night Light

KEEP THIS USER GUIDE FOR FUTURE REFERENCE  
Always retain your proof of purchase in case of warranty service.  
AUSTRALIA: www.oricom.com.au  
NEW ZEALAND: www.oricom.co.nz

### User Guide OLS50

Product Description.....	2
Pack Contents.....	2
Product Specifications.....	2
Product Overview.....	3
Features.....	4
How to Power On.....	4
Basic Operation.....	5
Volume Adjustment.....	5
Turn On/Off Night Light.....	5
Timer Function.....	5
Saving After Shutting Down.....	6
Battery Using Instructions.....	6
Warnings.....	6

### Warning

Risk of suffocation!  
Keep all packaging materials and protective foils out of reach of children.

### Need Help?

If you need assistance setting up or using your Oricom product now or in the future, call Oricom Support.  
Australia 1300 889 785 or (02) 4574 8888  
www.oricom.com.au  
Mon-Fri 8am – 6pm AEST  
New Zealand 0800 67 42 66  
www.oricom.co.nz  
Mon-Fri 10am – 8pm NZST

1

Thank you for choosing the Oricom OLS50 Portable Sound Soother with Night Light. This cute owl shaped night light includes soothing nature sounds, lullabies and white noise to assist with the sleep routine of your child. Portable and battery powered, this device can travel with you as required, and is a beautiful addition to any nursery.

### Pack Contents:

- 1 x OLS50 Soothing Sound Soother with Night Light
- 1 x User Guide
- 1 x Adjustable Strap
- 1 x Screwdriver kit

### Product Specifications:

Speaker Parameter	2X8Ω 1W
Product Material	ABS
Input Parameter	1.5V 2AA


WARNING: This product is not a toy, please keep out of reach of children. Do not place the soother inside the baby's cot, pram, or car seat.

This product contains small parts including the battery door and screws which could pose a choking hazard. Take care when inserting and replacing batteries.

2

### Product Overview

- |                 |   |
|-----------------|---|
| 1. Light ON/OFF | 6. Nature Sounds, Shusher Sound and White Noise |
| 2. VOL +        | 7. Lullaby                                      |
| 3. VOL -        | 8. Light  |
| 4. Timer        | 9. Right Speaker                                |
| 5. Power        | 10. Left Speaker                                |



3

## 背面

### Features

- Two built-in nature sounds, one shushing sound and one white noise.
- Three soothing lullabies.
- Built-in speakers. Supports 10 levels of volume adjustment.
- Three timer options, including: 30 mins, 60 mins and timer off.
- Soft night light that can be turned on and off.
- Battery Powered. 2 x 1.5V Alkaline batteries (not included)
- Low battery warning.

### Powering On the OLS50

First, use the included screwdriver to remove the screw securing the battery cover. Insert 2 x 1.5V AA Alkaline batteries, ensuring that the "+" and "-" marks on the battery slot are aligned with the battery polarities. Fit the battery cover on and secure with the screw.

Press the **Power Button** for 1 second to turn on the device. The machine will turn on with default settings activated. Press and hold the **Power Button** for 2 seconds, and the device will shutdown.



4

### Basic Operation

The OLS50 includes 2 Nature Sounds (Ocean Wave and River), a White Noise sound, a shusher sound and 3 lullabies (Rock-a-bye, Cradle and Twinkle). Pressing the Shhh button will switch between the nature sounds, white noise and shusher in sequence. Pressing the music icon will switch between the lullabies.

### Volume Adjustment

Press the VOL+/VOL- buttons to increase and decrease the volume on the unit. Pressing the volume adjustment button for a prolonged period will adjust volume in a stepless manner. When the "di di" tone is heard, volume has been adjusted to the maximum level.

**Note:** Lullabies are not turned off by adjusting the volume to zero. User must select the power button to turn the lullabies off completely, and to avoid battery drainage.

### Turn On/Off Night Light

When powered on, switch the button to the right to turn off the light.

Switch the button to the left to turn on the light.

### Timer Function

30 minutes, 60 minutes and OFF are the timer options available. If switched to OFF, the device will continue to play until the batteries run out.

If you want to use the OLS50 after the device has shut down by the timer function, press and hold the power button for 3 seconds, and the device will turn on, restored to previous settings.

**Note:** If the timer is not required, turn the timer to the OFF position.

5

### Saving Settings After Shutting Down

The OLS50 has a memory function that allows it to save the last working status and settings (volume and music), when the unit is turned off. When powered on, saved settings will remain. If you need to restore the OLS50 to the factory settings, turn the product on and press and hold the VOL+ and VOL- buttons at the same time for approximately 4 seconds. The device will now reset. Turn on the OLS50 in the usual way, and the default settings (Volume level 6 and Rock-a-bye lullaby) will be selected.

**Note:** When replacing the batteries, the OLS50 will revert to factory settings.

### Low Battery Instructions

When the OLS50 low battery warning sounds: "Battery low, please replace with new ones", this means that the batteries are in need of replacing. If batteries are not replaced in time, the device will shut down and revert to factory settings.

**Note:** Ensure that both batteries are replaced at the same time. Remove the batteries if the product is to be stored, or not used, for more than 1 month.

### Warnings

- DO NOT disassemble any part of the device, other than the removal of the battery cover, during battery replacement.
- Replacing the batteries should be undertaken by adults only.
- Observe correct battery polarity.
- This product is not waterproof. Avoid any contact with liquid.

6

### Express Warranty (Australia)

This Express Warranty is provided by Oricom International Pty Ltd ABN 46 086 116 369, Unit 1, 4 Sovereign Place, South Windsor NSW 2756, herein after referred to as "Oricom". Oricom products come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure. Oricom warrants that the product is free from defects in materials or workmanship during the Express Warranty Period. This Express Warranty does not extend to any product from which the serial number has been removed or was purchased outside of Australia.

Nothing in this Express Warranty excludes, restricts or modifies any condition, warranty, guarantee, implied term, right or remedy pursuant to the Australian Consumer Law and which may not be so excluded, restricted or modified. For such conditions, terms, guarantees and warranties that cannot be excluded, restricted or modified, Oricom limits the remedies available to extent permitted in the relevant legislation. Except with respect to rechargeable battery cells and rechargeable battery packs (if supplied), the Express Warranty Period will be 12 months from the date of purchase of the product evidenced by your dated sales receipt. You are required to provide proof of purchase as a condition of receiving Express Warranty services. Rechargeable battery cells and rechargeable battery packs (if supplied) with this product are covered under this warranty for a period of 6 months.

7

## 封面

## 封底

## 正面

<p>You are entitled to a replacement product or repair of the product at our discretion according to the terms and conditions of this document if your product is found to be faulty within the Express Warranty Period. This Express Warranty extends to the original purchaser only and is not transferable.</p> <p>Products distributed by Oricom are manufactured using new materials or new and used materials equivalent to new in performance and reliability. Spare parts may be new or equivalent to new. Spare parts are warranted to be free from defects in material or workmanship for thirty (30) days or for the remainder of the Express Warranty Period of the Oricom branded product in which they are installed, whichever is longer. During the Express Warranty Period, Oricom will where possible repair and if not replace the faulty product or part thereof. All component parts removed under this Express Warranty become the property of Oricom. In the unlikely event that your Oricom product has a recurring failure, Oricom may always, subject to the Competition and Consumer Act 2010, at its discretion, elect to provide you with a replacement product of its choosing that is at least equivalent to your product in performance.</p> <p>No change to the conditions of this Express Warranty is valid unless it is made in writing and signed by an authorised representative of Oricom. Oricom will not be liable under this Express Warranty, and to the extent permitted by law, will not be liable for any defect, loss, damage or injury arising out of or in connection with a:</p> <p>10. failure by you to adhere to the warnings and follow the instructions set out in this user guide for the proper installation and use of the product;</p> <p>11. willful misconduct or deliberate misuse by you of the product;</p> <p style="text-align: right;">8</p>	<p>12. any external cause beyond our control, including but not limited to power failure, lightning or over voltage; or</p> <p>13. modification to the product or services carried out on the product by anyone other than Oricom or Oricom's authorised service provider.</p> <p><b>How to make a claim under your Express Warranty in Australia</b></p> <p>Oricom has a simple warranty process for you to follow:</p> <ul style="list-style-type: none"> <li>• Please call our Customer Support Team on 1300 889 785, or email <a href="mailto:support@oricom.com.au">support@oricom.com.au</a>.</li> <li>• A Customer Support Team member will verify, after troubleshooting with you, if your product qualifies under warranty. If so, they will give you a Product Return Authorisation number.</li> <li>• We will then email or fax a Return Authorisation form and a Repair Notice (if necessary), together with instructions on how to return the goods for warranty service.</li> </ul> <p>Please note that if a Customer Support Team member advises that your product does not qualify for return, this warranty does not apply to your product. Products that are authorised to be returned to Oricom in Australia must include all of the following:</p> <ul style="list-style-type: none"> <li>• A completed Return Authorisation form</li> <li>• A copy of your Proof of Purchase (please keep your original copy)</li> <li>• The faulty product, including all accessories.</li> </ul> <p style="text-align: right;">9</p>	<p>Send the approved returns to:</p> <p>Oricom International Pty Ltd Locked Bag 658 South Windsor NSW 2756 Australia</p> <p>Please note that this Express Warranty excludes expenses incurred by you in returning any faulty product to us. You must arrange and pay any expenses incurred (including postage, delivery, freight, transportation or insurance of the product) to return the faulty product to us, however, we will arrange delivery of the repaired or replaced faulty product to you.</p> <p><b>Important Information - Repair Notice</b></p> <p>Please be aware that the repair of your goods may result in the loss of any user-generated data (such as stored telephone numbers, text messages and contact information). Please ensure that you have made a copy of any data saved on your goods before sending for repair. Please also be aware that goods presented for repair may be replaced by refurbished goods or parts of the same type rather than being repaired.</p> <p style="text-align: right;">10</p>	<p><b>ORICOM CUSTOMER SUPPORT</b></p> <p>Oricom have a trained and dedicated team of Customer Support Representatives, each with the knowledge and resources to assist in answering your questions quickly and efficiently.</p> <p><b>Oricom Support - Australia</b> For all product enquiries, troubleshooting or to discuss the range of Oricom products, feel free to contact Oricom or visit our website for answers to frequently asked questions.</p> <p><b>1300 889 785</b> Monday - Friday 8am – 6pm AEST Email: <a href="mailto:support@oricom.com.au">support@oricom.com.au</a> <a href="http://www.oricom.com.au">www.oricom.com.au</a></p> <p><b>Oricom Support - New Zealand</b></p> <p><b>0800 674 266</b> Monday - Friday 10am - 8pm NZST Email: <a href="mailto:support@oricom.co.nz">support@oricom.co.nz</a> <a href="http://www.oricom.co.nz">www.oricom.co.nz</a></p> <div style="text-align: center;">  </div> <p style="text-align: right;">Ref: 11042019</p>
--	---	--	--

## 背面

--	--	--	--