

oricom®



**WRC001 Wireless Reversing Camera  
with Magnetic Base  
User Manual**

Smart device not included.

95mm\*80mm

## Warnings

- The reversing camera is designed to be installed temporarily on the rear of a vehicle or trailer, with the convenient magnetic mounting feature. This product is intended to assist in parking a vehicle, requiring initial installation by a user outside of the vehicle, to be manually turned on via a switch on the camera, and then viewed through a mobile app in vehicle, securely mounted in an appropriate smart phone holder. All of this is to be done prior to the vehicle moving. Once in use, the user need not interact with the phone while the vehicle is in motion. This feature is designed to provide convenience and safety.
- Road Safety - Check the laws and regulations on the use of mobile phones in your area, you must comply with all safety warnings and regulations regarding mobile device usage while operating a vehicle.

## Pack Contents

- 1 x WRC001 Wireless reversing camera
- 1 x Magnetic base
- 1 x USB Charging cable (5V Power Adaptor not supplied)
- 1 x Velcro mounting tape\*

### \*Velcro Tape Installation Instructions

It is strongly recommended that the surface is thoroughly cleaned prior to application using IPA wipes, you can also use a primer to increase adhesion further.

Installation temperature should be between 20-27°C, The pressure sensitive adhesive tape requires a clean dry surface and firm even pressure (15psi) to ensure good contact with the surface of the substrate to which it is being applied.

It is advised to wait one hour after tape installation before installing the camera.

## Specifications

Battery Capacity	2160mAh
Battery Voltage	3.7V
Recharge Time	Approx. 4.5h
Max Recharge Current	480mA
Operating Current	260mA
Transmit Power	17.3dBm (53.5mW)
Wireless Communication Format	WiFi
Wireless Transfer Distance	Up to 15m (without obstruction)
Ingress Protection Rating	IPX6

### Key Features:

- View camera feed on FREE App
- Infrared night vision (Black and white image)
- Colour daytime view
- Waterproof IPX6
- Up to 15m Range
- USB Charging
- Included Velcro for Flexible Mounting Position.

## Android Platform Instructions

To use the WRC001 Wireless Camera on your Android powered smart device, scan the below QR code, or search: safetycam

Scan here to download App from Google Play store



### Instructions for using the safetycam App:

- 1) Once the installation of the app has occurred, open the application on the smart device.
- 2) The ON/OFF Button on the camera can now be pressed to turn the device on.
- 3) Once powered on, the blue light on the front of the camera will illuminate. Once you have seen the blue light, and the App is open on your smart device, the screen on the right will appear on first use:



Choose **SONIX** device and press confirm.

3

## Android Platform Instructions

**NOTE:** If connection between the wireless camera and the smart device has been successful, you will now see the camera feed on screen.

A full recharge will take approximately 4.5 hours. To charge the camera, connect the supplied charging cable to a suitable 5V Power Adaptor. When connected and charging, a RED LED will illuminate to show charge in process.



### Icons displayed in the App KEY

	Wi-Fi set up
	Flip image right and left
	Click here to take a picture
	Saved images
	Turn on/ off grid distance lines

4

## Apple iOS App Store Instructions

To use the WRC001 Wireless Camera on your Apple iOS powered smart device, scan the below QR code, or search: safetyeye

Scan here to download App from  
Apple iOS App store



### Instructions for using the safetyeye App:

- 1) Once the installation of the app has occurred on your smart device, the ON/OFF Button on the camera can now be pressed to turn the device on.
- 2) Once powered on, the blue light on the front of the camera will illuminate.  
Once you have seen the blue light, open the Wi-Fi settings and locate \*SONIX\*\*\*\* to connect to the Wireless camera. After you have connected, open the App.

**NOTE:** If connection between the wireless camera and the smart device has been successful, you will now see the camera feed on screen.

A full recharge will take approximately 4.5 hours. To charge the camera, connect the supplied charging cable to a suitable 5V Power Adaptor. When connected and charging, a RED LED will illuminate to show charge in process.

## Apple iOS App Store Instructions

Icons displayed in the App KEY	
	Wi-Fi set up
	Flip image right and left
	Click here to take a picture
	Saved images
	Turn on/ off grid distance lines

## Mounting Bracket Installation

This camera includes flexible mounting options, and a user can choose to use either the magnetic mounting base for simple installation, or the included Velcro for an installation where magnetic surface is not apparent.

The viewing angle can be altered using the gimbal screws supplied with the bracket. Simply place the wireless camera between the bracket arms, and tighten the gimbal screws until they are secure in the preferred mounting option.

**NOTE:** There is an example mounting suggestion on the rear side of the WRC001 giftbox supplied with the product.

### **Need Help?**

If you need assistance setting up or using your Oricom product now or in the future, call Oricom Support.

Australia	(02) 4574 8888 www.oricom.com.au Mon-Fri 8 am – 6 pm AEST
New Zealand	0800 67 42 66 www.oricom.co.nz Mon-Fri 10 am – 8 pm NZST

### **How to make a claim under your Express Warranty in Australia**

Oricom has a simple warranty process for you to follow:

- Please call or email our Customer Support Team, 02 4574 8888 or support@oricom.com.au.
  - A Customer Support Team member will verify after troubleshooting with you if your product qualifies under warranty. If so, they will give you a Product Return Authorisation number.
  - We will then email a Return Authorisation form and a Repair Notice (if necessary), together with instructions on how to return the product for warranty service.
- Please note that if a Customer Support Team member advises that your product does not qualify for return, this warranty does not apply to your product. Products that are authorised to be

returned to Oricom in Australia must include all of the following:

- A completed Return Authorisation form
- A copy of your Proof of Purchase (please keep your original copy)
- The faulty product, including all accessories.

Send the approved returns to:

Oricom International Pty Ltd  
Locked Bag 658  
South Windsor NSW 2756 Australia

Please note that this Express Warranty excludes expenses incurred by you in returning any faulty product to us. You must arrange and pay any expenses incurred (including postage, delivery, freight, transportation or insurance of the product) to return the faulty product to us, however, we will arrange delivery of the repaired or replaced faulty product to you.

### **Important Information Repair Notice**

Please be aware that the repair of your products may result in the loss of any user-generated data (such as stored telephone numbers, text messages and contact information). Please ensure that you have made a copy of any data saved on your product before sending for repair.

Please also be aware that products presented for repair may be replaced by refurbished products or parts of the same type rather than being repaired.

### **Express Warranty (Australia)**

This Express Warranty is provided by Oricom International Pty

Ltd ABN 46 086 116 369, Unit 1, 4 Sovereign Place, South Windsor NSW 2756, herein after referred to as "Oricom".  
Oricom warrants that the product is free from defects in materials or workmanship during the Express Warranty Period. This Express Warranty does not extend to any product from which the serial number has been removed or was purchased outside of Australia.

The benefits of this Express Warranty are in addition to other rights and remedies you may have under the Australian Consumer Law. Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure. In the event of a minor failure, Oricom reserves the right to choose to repair or replace the product.

The Express Warranty Period will be a period of 12 months beginning on the date of purchase of the product evidenced by your dated sales receipt. You are required to provide proof of purchase as a condition of receiving Express Warranty services. You are entitled to a replacement product or repair of the product at our discretion according to the terms and conditions of this document if your product is found to be faulty within the Express Warranty Period. This Express Warranty extends to the original purchaser only and is not transferable.

Products distributed by Oricom are manufactured using new materials or new and used materials equivalent to new in

performance and reliability. Spare parts may be new or equivalent to new. Spare parts are warranted to be free from defects in material or workmanship for thirty (30) days or for the remainder of the Express Warranty Period of the Oricom branded product in which they are installed, whichever is longer. During the Express Warranty Period, Oricom will where possible repair and if not replace the faulty product or part thereof. All component parts removed under this Express Warranty become the property of Oricom. In the unlikely event that your Oricom product has a recurring failure, Oricom may always, subject to the Competition and Consumer Act 2010, at its discretion, elect to provide you with a replacement product of its choosing that is at least equivalent to your product in performance.

No change to the conditions of this Express Warranty is valid unless it is made in writing and signed by an authorised representative of Oricom.

Oricom will not be liable under this Express Warranty, and to the extent permitted by law will not be liable for any defect, loss, damage or injury arising out of or in connection with a:

- Failure by you to adhere to the warnings and follow the instructions set out in this user guide for the proper installation and use of the product;
- Willful misconduct or deliberate misuse by you of the product;
- Any external cause beyond our control, including but not limited to power failure, lightning or over voltage; or
- Modification to the product or services carried out on the product by anyone other than Oricom or Oricom's authorised service provider.