

IMPORTANT - BEFORE USE

BEFORE FIRST USE, please ensure you pair the camera/s included in your monitor pack, simply follow the steps below to pair.


Setting Up the Baby Unit (Camera)

Power adaptor markings

Please ensure you connect the correct power adaptor to parent and baby units.


Each power adaptor is marked with a drawing showing the parent unit or camera unit as follows:

Connecting the power adaptor to the baby unit:




- Connect the small plug of the power adaptor to the rear of the Baby Unit. The other end will plug into the power socket.
- Only use the supplied adaptor (5V DC/1.5A).

Baby Unit Power Adaptor Marking



Parent Unit Power Adaptor Marking



Aligning the baby unit

To get the best performance, place your baby unit between one and two metres away from your baby. Point the baby unit towards the baby or object you want to monitor. Check that the baby or object is suitably displayed on the parent unit screen.

Connecting the Camera




Press MENU button.

- 1) Select Camera icon. Press "OK" button to confirm.
- 2) Select camera position under "Add Camera" (SC895 supports up to 4 cameras). Press OK button to confirm.
- 3) Press the "Pair" button on the bottom of the camera unit to pair within 30 seconds.

Warning

Do not place the AC Adaptor cable in a high "wear and tear" location. Never use a frayed or compromised cord.

PAIR Button.



FOR ALL OTHER INSTRUCTIONS, PLEASE REFER TO YOUR SC895 USER GUIDE.