



Designer phone TP6



User Guide

Keep for future reference

Warnings

Do not use your telephone during an electrical storm thunderstorm as it is possible to get an electric shock. Refer to information contained in Telstra White pages directory.

The earpiece of the handset may attract small metal objects such as staples and pins. Care should be taken when placing the handset near these items.

Temperature and ambient conditions

The telephone is designed for indoor use (temperature range of -10 °C to 50 °C). Do not install the telephone in areas where there is the risk of an explosion, excessive exposure to smoke, dust, vibrations, chemicals, moisture, and heat. The unit must not be installed in damp locations such as a bathroom or laundry, do not expose the unit to direct sunlight.

Cleaning and care

The surface of the case can be cleaned with a dry, soft, lint-free cloth. Never use cleaning agents, particularly aggressive solvents. Apart from occasional cleaning of the case, no other care is necessary. The rubber feet of the base station are not resistant to all cleaning agents. The telephone feet do not normally leave any marks on the surface. However, on account of the multitude of varnishes and surface finishes used, surface marks caused by the feet of the unit cannot be ruled out.

Location of controls



- 1 Mute button
- 2 Recall button
- 3 Memory button
- 4 Redial button
- 5 Store button
- 6 Recall setting switch
- 7 Ringer Hi/Lo/Off switch



The A-Tick symbol indicates that this product complies with all current Australian ACA standards.

1.1 Notes for operation in New Zealand

The grant of a Telepermit for any item of terminal equipment indicates only that Telecom has accepted that the item complies with the minimum conditions for connection to its network. It indicates no endorsement of the product by Telecom, nor does it provide any sort of warranty. Above all, it provides no assurance that any item will work correctly in all respects with another item of Telepermitted equipment of a different make or model, nor does it imply that any product is compatible with all of Telecom's network services. This equipment shall not be set to make automatic calls to the Telecom "111" Emergency Service. This equipment may not provide for the effective hand-over of a call to another device connected to the same line.

This device may be subject to ringing or bell tinkle when certain other devices are connected to the same line. If this occurs, the problem should not be referred to the Telecom Faults Service.

REN (RN for New Zealand)

The REN (Ringer Equivalence Number) or (RN) is of significance only if you wish to connect more than 1 telephone to your telephone line. A standard telephone line has a maximum REN capacity of 3 (RN of 5). It is possible to connect 3(5) devices with a REN of 1 (RN of 1) with no degradation to the product's performance. Exceeding this limit may cause the volume of the ringer in any phone to decrease or not ring at all.

1.2 Quick Setup

The Oricom TP6 telephone is used like any conventional telephone and works with all modern telephone exchanges using the tone dialling system. Plug one end of the line cord into the bottom of the phone and the other into the wall socket using the plug supplied.

1.3 Check contents of pack

The following items are supplied in this pack:

one telephone base	one telephone handset
one short telephone cable	one long telephone cable
one warranty card	one operating Manual

1.4 Connect the line cord

Plug one end of the telephone cable (long for desk installation) into the wall socket. Plug the other end into the socket located in the indentation on the base of the telephone. Then feed the cable through the cable guide.

1.5 Wall mounting

Method A. At the desired location drill two holes one above the other, 83mm apart, use two screws (not supplied) for fixing and leave them protruding 5mm from the wall. Now place the telephone base over the screws and gently push forwards and then downwards.

Method B If you wish to fit to an existing telephone wall plate with modular connector simply plug in the short telephone line cord into the base of the phone and plug the other end into the telephone wall plate socket. Position the mounting holes on the base of the phone over the two protruding holes on the wall plate. Gently push the phone flush against the wall plate then slide the phone downwards locking it into place.

1.6 Adjustable ringer volume

You can use the **RINGER HI/LO/OFF** slide switch located on the side of the telephone to select the incoming ring volume. Should you not want to be disturbed, use select **OFF** position.

1.7 Last number redial

If the number you have dialled is engaged or you were unable to get through to anybody, simply replace the handset. The last number dialled will be saved in the telephone memory. To use the redial facility, proceed as follows:

1. Lift the handset.
2. Press the **REDIAL** button the last saved redial number will now be dialled.

1.8 Recall button

You will use the **RECALL** button when using your network operator's services such as call waiting etc. If this feature is not working check the position of the Recall switch on the side of the phone. In Australia it should be set at 100ms and in New Zealand 600ms.

1.9 Storing and dialling numbers from memory

You can store up to 10 numbers in memory and dial those numbers quickly.

Storing a number in memory:

1. Pick up the handset.
2. Press **STORE** button.
3. Dial the number (up to 16 digits) you wish to store.
4. Press **STORE** button and then enter the desired memory location (0,1 ...9)
5. Replace handset.

Dialling a Stored Number:

Pick up the handset and press **MEMORY** button. Then press the memory location number (0, 1 ...9). The telephone then automatically dials the number stored in that location.

1.10 Muting the microphone

You can switch off the microphone during a call using the **MUTE** button. It is then possible to speak without the other party hearing you. You can still hear the other party.

To mute the microphone, press and hold the **MUTE** button during a call. Release the **MUTE** button and you can continue the call as normal.

1.11 Important information

Troubleshooting

If you feel this product is not working correctly please consult the user guide and ensure that you are using the product in accordance with the instructions.

Remove all extra telephone equipment and connect only this telephone directly to the telephone socket.

If the fault is still present, connect another telephone (if available) to the telephone socket. The results will show you whether the fault lies with this product or with the telephone line. If this product is working correctly the fault is on the telephone line. Please contact your network operator for assistance

In the case of technical problems with this product please consult our website for further information or send us an email for a prompt response to your enquiry.

Warranty Information

This product is covered by a 12 month warranty against defective workmanship or parts, effective from the date of purchase.

The warranty does not extend to damage caused by misuse, negligence, excessive voltage, faults on the telephone line or lightning. This warranty in no way affects your statutory rights. Full details of the warranty are contained in the enclosed warranty card.

Technical support

In the unlikely event of a fault during this period, please consult our website for assistance or send us an email for a prompt response to your enquiry. If the product is then found to be faulty you will be asked to return it directly to us with a copy of the purchase receipt.

For further information about the Oricom range of products please visit our website.

Australia

Oricom International Pty Ltd
ABN 46 086 116 369
PO Box 5681
South Windsor, NSW 2756

Customer support

Email:
support@oricom.com.au
Web: www.oricom.com.au
Fax: (02) 4572 0939
Ph: 1300 889 785

New Zealand

Atlas Gentech (NZ) Ltd,
Private Bag 14927,
Panmure,
Auckland

Customer Support

Email:
support@atlasgentec.co.nz
Fax (09) 5742722
Ph: 0900 50025 (Toll Call)