
QUICK START GUIDE

oricom.

For a full explanation of all features and instructions, please refer to the User Guide (available for download from www.oricom.com.au/support/).

1. Contents Inside Box

Model: OBHGPLUS





OBHGPLUS is not a medical device.

It is not intended to diagnose, treat, cure, or alleviate any disease or health condition, including, but not limited to, Sudden Infant Death Syndrome (SIDS). False positive or false negative readings about your baby's patterns are a potential risk.

This product is only intended to assist you in tracking your baby's wellbeing and is not intended to replace you as a caregiver. You are responsible for the health and wellbeing of your baby and should follow safe sleep, health, and care guidelines.


To obtain optimal and safe user experience, please carefully read, understand, and follow all instructions and warnings prior to use.

2. Overview of Product

Base Station

- 1. Brightness up
- 2. Brightness down
- 3. Night light
- 4. ConnectChat™
- 5. Soothing sound
- 6. Volume down
- 7. Volume up

- 8. Charging indicator for Smart Sensor
- 9. Charging pins
- 10. Power ON-OFF switch
- 11. Pairing LED indicator
- 12. Pair Button (HubbleClub for Partners and BT speaker)
- 13. Power Socket
- 14. Power On indicator



Smart Sensor

- 1. Oxygen sensor
- 2. Power ON-OFF switch
- 3. Charging points
- 4. Heart rate sensor



3. Getting Started

3.1. Power on Base Station

Connect the Base Station through the USB charging cable provided with a DC5V 2A power adaptor (not included).



3.2. Connect to HubbleClub for Partners





- Scan the QR code with your smart device and download HubbleClub for Partners App from the App Store for iOS devices or from the Google Play™ Store for Android™ devices.
- Install HubbleClub for Partners App on your device.
- Open the HubbleClub for Partners App on your compatible smartphone or tablet, follow the instructions of HubbleClub for Partners App to create your HubbleClub for Partners account.
- 2. Press and hold Pair button at the bottom of the Base Unit, you will hear a voice prompt "Ready for Pairing" when the device enters HubbleClub for Partners App pairing mode.
- Select Wellness and then OBHGPLUS, follow the in-app instructions to connect Oricom OBHGPLUS to your account.

- 4. If registration fails or connection cannot be completed within 60s, connection mode will be turned off, please try again by repeating steps 1 to 3.
- 5. Full control and full features can be accessed in the HubbleClub for Partners App.

4. Operation of Base Station

4.1. Control Night Light

- 1. Tapping the Night Light '\(\docume{\gamma}\) icon on the top of the Base Station will change the colour of the night light. Tapping again with cycle through all the colours.
- 2. The brightness of the night light can be adjusted by tapping the brightness up ☆ and brightness down ☼ icons.

4.2. Control Soothing Sound

- 2. The volume of the soothing sound can be adjusted by tapping the volume up (1) and volume down (1) icons.

4.3. ConnectChat™

ConnectChat $^{\text{TM}}$ in OBHGPLUS is designed in such a way that both parent and child can send voice recorded messages to each other.

- Tap and hold ConnectChat™ icon until a beep tone is heard from the Base Station, release and start recording a voice message. (Voice message recording time is 20 sec.)
- - Parent will receive an app notification when new voice message has arrived.
 - Parent in reply can record their voice message through the app creating a bi-directional conversation.

4.4. Use Base Station as a BT Speaker

- Press and hold the Pair button on the bottom of Base Station for 2 seconds. You will hear
 a beep tone and the Pair LED indicator blinks in blue colour when the device enters BT pairing
 mode.
- 2. Go to the Set-Up menu of your mobile phone. Then go to BT Connection.
- 3. Find the Device name "Guardian Audio" and connect.
- 4. If the connection fails, please try again by repeating steps 1 to 3.
- 5. Stream the audio from your mobile phone to the Base Station.



Note:

Once BT is disconnected, reactivate BT by short pressing Pair button, and reconnect Base Station to your mobile phone.

5. Smart Sensor Operation

5.1. Device Power and Charging

- Install the power adaptor (not supplied) and insert the USB cable into the Base Station
- 2 Use the On/Off switch on the sensor to turn On/Off
- 3. Charge the device by laying the sensor on the charging pins of the base station. The base station must be turned on for the sensor to charge.
- 4. Place the sensor on the base station as per the illustration shown below.



CHARGING


correct position for charging 1mm away from the indication line

NOT CHARGING


incorrect position for charging covering the indication line

RGING

NOT CHARGING
incorrect position for charging
approximately 5mm away from
the indication line








5. The charging indicator will turn red during charging and will turn blue when the sensor is fully charged.

Tip: Switch off the sensor to charge when the battery is very low.

5.2. Device Placement

- Place the sensor on the smallest part of your child's ankle just above the ankle bone. The sensor
 must be facing the outside of the ankle (as shown in the picture below). Use the Velcro on the
 straps to secure the sensor in place.
- 2. To avoid discomfort, red marks, pressure sores or blisters due to incorrect use, ensure the device is fitted snugly but not too tight. Different strap lengths are available for different leg widths for maximum comfort
- 3. The operation distance between the wearable sensor and base station works best between 2 3 meters



6. Important Safety Information

- Your Oricom baby monitor is designed to be an aid and should not be used as a substitute for responsible and proper adult supervision of a child.
- Your baby monitor is not a medical device, nor a device to prevent cases of Sudden Infant Death Syndrome (SIDS) or "cot death", and you should not rely on it for your baby's wellbeing. It is important that you regularly check on your baby personally.
- Make sure the baby unit, parent unit and mains adaptor cables are kept out of reach of your baby and other young children at all times, as far away from the baby as practical.
- Never place the baby unit or parent unit inside your baby's cot, bed or playpen.
- Never use or place your parent or baby unit in or near moisture or water (e.g. near bath or pool).
 Immersing in water could cause electric shock and even death.
- The installation location plays an important role in ensuring proper operation. Therefore, maintain a
 distance of at least one metre from other electronic equipment, such as microwave ovens or Wi-Fi
 devices, otherwise they could cause interference.
- During continual use the baby unit power adaptors may become warm to the touch. This is normal
 and should not be a concern.
- This product is not a toy, do not allow children to play with it.
- This device is designed for indoor use only.

7. General Information

Express Warranty (Australia)

This Express Warranty is provided by Oricom International Pty Ltd ABN 46 086 116 369, Unit 1, 4 Sovereign Place, South Windsor NSW 2756, herein after referred to as "Oricom".

Oricom warrants that the product is free from defects in materials or workmanship during the Express Warranty Period. This Express Warranty does not extend to any product from which the serial number has been removed or was purchased outside of Australia.

The benefits of this Express Warranty are in addition to other rights and remedies you may have under the Australian Consumer Law. Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure. In the event of a minor failure, Oricom reserves the right to choose to repair or replace the product.

The Express Warranty Period will be a period of 24 months beginning on the date of purchase of the product evidenced by your dated sales receipt. You are required to provide proof of purchase as a condition of receiving Express Warranty services.

You are entitled to a replacement product or repair of the product at our discretion according to the terms and conditions of this document if your product is found to be faulty within the Express Warranty Period. This Express Warranty extends to the original purchaser only and is not transferable.

Products distributed by Oricom are manufactured using new materials or new and used materials equivalent to new in performance and reliability. Spare parts may be new or equivalent to new. Spare parts are warranted to be free from defects in material or workmanship for thirty (30) days or for the remainder of the Express Warranty Period of the Oricom branded product in which they are installed,

whichever is longer. During the Express Warranty Period, Oricom will where possible repair and if not replace the faulty product or part thereof. All component parts removed under this Express Warranty become the property of Oricom. In the unlikely event that your Oricom product has a recurring failure, Oricom may always, subject to the Competition and Consumer Act 2010, at its discretion, elect to provide you with a replacement product of its choosing that is at least equivalent to your product in performance.

No change to the conditions of this Express Warranty is valid unless it is made in writing and signed by an authorised representative of Oricom. Oricom will not be liable under this Express Warranty, and to the extent permitted by law will not be

liable for any defect, loss, damage or injury arising out of or in connection with a: 1. Failure by you to adhere to the warnings and follow the instructions set out in this user guide for

- the proper installation and use of the product;
- 2. Willful misconduct or deliberate misuse by you of the product;
- 3. Any external cause beyond our control, including but not limited to power failure, lightning or over voltage: or
- 4. Modification to the product or services carried out on the product by anyone other than Oricom or Oricom's authorised service provider.

How to make a claim under your Express Warranty in Australia

- Oricom has a simple warranty process for you to follow:
- Please call or email our Customer Support Team, 02 4574 8888 or support@oricom.com.au.
- A Customer Support Team member will verify after troubleshooting with you if your product qualifies under warranty. If so, they will give you a Product Return Authorisation number.
- We will then email a Return Authorisation form and a Repair Notice (if necessary), together with instructions on how to return the product for warranty service.

Please note that if a Customer Support Team member advises that your product does not qualify for return, this warranty does not apply to your product. Products that are authorised to be returned to Oricom in Australia must include all of the following:

- A completed Return Authorisation form
- A copy of your Proof of Purchase (please keep your original copy)
- The faulty product, including all accessories.

Send the approved returns to:

Oricom International Pty Ltd

Locked Bag 658

South Windsor NSW 2756 Australia

Please note that this Express Warranty excludes expenses incurred by you in returning any faulty product to us. You must arrange and pay any expenses incurred (including postage, delivery, freight, transportation or insurance of the product) to return the faulty product to us, however, we will arrange delivery of the repaired or replaced faulty product to you.

Important Information - Repair Notice

Please be aware that the repair of your products may result in the loss of any user-generated data (such as stored telephone numbers, text messages and contact information). Please ensure that you have made a copy of any data saved on your product before sending for repair. Please also be aware that products presented for repair may be replaced by refurbished products or parts of the same type rather than being repaired.

Oricom Customer Support

Oricom have a trained and dedicated team of Customer Support Representatives, each with the knowledge and resources to assist in answering your questions quickly and efficiently.

Oricom Support - Australia

For all product enquiries, troubleshooting or to discuss the range of Oricom products, feel free to contact Oricom or visit our website for answers to frequently asked questions.

(02) 4574 8888 / Monday - Friday 8am – 6pm AEST Email: support@oricom.com.au / www.oricom.com.au

Oricom Support - New Zealand

0800 674 266 / Monday - Friday 10am - 8pm NZST

Email: support@oricom.co.nz

Ref: 2023-02-23

oricom.

All rights reserved

Printed in China Version 5.0





